



UNITEDTEK CORPORATION

Email: utk@seed.net.tw

UT NO.	OEM NO.	MAKE	DESCRIPTION	PART	NOTE
UTC06-4709	51350-S5A-A02	ACURA	RSX 02-06	CONTROL ARM	FRONT LOWER W/O BJ RH
UTC06-3930	51350-SDB-A00	ACURA	TSX 04-08	CONTROL ARM W/O BJ	LOW,RH
UTC06-1941	51350-SR3-A02	ACURA	INTEGRA 94-01	CONTROL ARM	FRONT LOWER W/O BJ RH
UTC06-4711	51350-TA0-A00	ACURA	TSX 09-14	CONTROL ARM	FRONT LOWER W/O BJ RH
UTC06-1950	51355-SK7-010	ACURA	INTEGRA 90-93	CONTROL ARM	FRONT LOWER W/O BJ RH
UTC06-4708	51360-S5A-A02	ACURA	RSX 02-06	CONTROL ARM	FRONT LOWER W/O BJ LH
UTC06-3931	51360-SDB-A00	ACURA	TSX 04-08	CONTROL ARM W/O BJ	LOW,LH
UTC06-1967	51360-SR3-A02	ACURA	INTEGRA 94-01	CONTROL ARM	FRONT LOWER W/O BJ LH
UTC06-4712	51360-TA0-A00	ACURA	TSX 09-14	CONTROL ARM	FRONT LOWER W/O BJ LH
UTC06-1975	51365-SK7-010	ACURA	INTEGRA 90-93	CONTROL ARM	FRONT LOWER W/O BJ LH
UTC06-1982	51450-S84-A01	ACURA	CL 01-03	CONTROL ARM	FRONT UPPER W/ BJ RH
UTC06-1982	51450-S84-A01	ACURA	TL 99-03	CONTROL ARM	FRONT UPPER W/ BJ RH
UTC06-1985	51450-SK7-043	ACURA	INTEGRA 90-93	CONTROL ARM	FRONT UPPER W/ BJ RH
UTC06-1987	51450-SP0-033	ACURA	LEGEND 91-95	CONTROL ARM	FRONT UPPER W/ BJ RH
UTC06-1993	51460-S84-A01	ACURA	CL 01-03	CONTROL ARM	FRONT UPPER W/ BJ LH
UTC06-1993	51460-S84-A01	ACURA	TL 99-03	CONTROL ARM	FRONT UPPER W/ BJ LH
UTC06-1996	51460-SK7-043	ACURA	INTEGRA 90-93	CONTROL ARM	FRONT UPPER W/ BJ LH
UTC06-1998	51460-SP0-033	ACURA	LEGEND 91-95	CONTROL ARM	FRONT UPPER W/ BJ LH
UTC06-4710	52360-SDA-A00	ACURA	TL 03-08	CONTROL ARM	REAR LOWER REAR R/L
UTC06-4710	52360-SDA-A00	ACURA	TSX 04-08	CONTROL ARM	REAR LOWER REAR R/L
UTC06-2054	52390-SM4-033	ACURA	VIGOR 92-94	CONTROL ARM	REAR,UPPER W/BJ RH
UTC06-3532	52390-SR3-000	ACURA	INTEGRA 94-01	CONTROL ARM REAR	UP,RH
UTC06-2063	52400-SM4-033	ACURA	VIGOR 92-94	CONTROL ARM	REAR,UPPER W/BJ LH
UTC06-3929	52400-SR3-000	ACURA	INTEGRA 94-01	CONTROL ARM	REAR UP,LH
UTC06-2291	96328495	DAEWOO	MAGNUS 99-	CONTROL ARM	FRONT UPPER W/O BJ LH
UTC06-2292	96328496	DAEWOO	MAGNUS 99-	CONTROL ARM	FRONT UPPER W/O BJ RH
UTC06-2295	96389488	DAEWOO	MAGNUS 99-	CONTROL ARM	FRONT LOWER W/ BJ LH
UTC06-2296	96389489	DAEWOO	MAGNUS 99-	CONTROL ARM	FRONT LOWER W/ BJ RH
UTC06-3913	96445371	DAEWOO	LANOS 98-02	CONTROL ARM	LOW, LH
UTC06-3914	96445372	DAEWOO	LANOS 98-02	CONTROL ARM	LOW, RH
UTC06-2284	96213117 LH	DAEWOO	LEGANZA 98-02	CONTROL ARM	FRONT LOWER W/ BJ LH
UTC06-2285	96213118 RH	DAEWOO	LEGANZA 98-02	CONTROL ARM	FRONT LOWER W/ BJ RH
UTC06-2286	96268439 LH	DAEWOO	NUBIRA 98-99	CONTROL ARM	FRONT LOWER W/ BJ LH
UTC06-2287	96268440 RH	DAEWOO	NUBIRA 98-99	CONTROL ARM	FRONT LOWER W/ BJ RH
UTC06-2288	96268454 LH	DAEWOO	NUBIRA 00-02	CONTROL ARM	FRONT LOWER W/ BJ LH
UTC06-2289	96268455 RH	DAEWOO	NUBIRA 00-02	CONTROL ARM	FRONT LOWER W/ BJ RH
UTC06-2290	96316765 R/L	DAEWOO	MATIZ 97-	CONTROL ARM	FRONT LOWER W/ BJ R/L
UTC06-1796	48068-87209	DAIHATSU	MOVE L601	CONTROL ARM	FRONT LOWER W/ BJ RH
UTC06-1796	48068-87209 RH	DAIHATSU	CUORE L501 96-98	CONTROL ARM	FRONT LOWER W/ BJ RH
UTC06-1797	48068-97203 RH	DAIHATSU	CUORE L501 96-98	CONTROL ARM	FRONT LOWER W/ BJ RH
UTC06-1798	48068-97401-000 RH	DAIHATSU	SIRION 98-	CONTROL ARM	FRONT LOWER W/ BJ RH
UTC06-1826	48069-87209	DAIHATSU	MOVE L601	CONTROL ARM	FRONT LOWER W/ BJ LH
UTC06-1826	48069-87209 LH	DAIHATSU	CUORE L501 96-98	CONTROL ARM	FRONT LOWER W/ BJ LH
UTC06-1827	48069-97203 LH	DAIHATSU	CUORE L501 96-98	CONTROL ARM	FRONT LOWER W/ BJ LH
UTC06-1828	48069-97401-000 LH	DAIHATSU	SIRION 98-	CONTROL ARM	FRONT LOWER W/ BJ LH
UTC06-1927	51350-S01-000	HONDA	DOMANI 96~00(AMERICAN BUILT)	CONTROL ARM	FRONT,LOWER ARM W / O BJ RH
UTC06-1928	51350-S04-G00	HONDA	CIVIC K800 96-00	CONTROL ARM	FRONT LOWER ARM W / O BJ RH
UTC06-4245	51350-S0V-A02	HONDA	ODYSSEY 99-04	CONTROL ARM	LOW, RH
UTC06-1929	51350-S10-A00	HONDA	CRV 97-00	CONTROL ARM	FRONT LOWER W/O BJ RH
UTC06-1930	51350-S3V-A01	HONDA	PILOT 03-05	CONTROL ARM	FRONT,LOWER ARM W / BJ RH
UTC06-4709	51350-S5A-A02	HONDA	CIVIC 02-05	CONTROL ARM	FRONT LOWER W/O BJ RH



UNITEDTEK CORPORATION

Email: utk@seed.net.tw

UT NO.	OEM NO.	MAKE	DESCRIPTION	PART	NOTE
UTC06-1931	51350-S5A-A03	HONDA	CIVIC FERIO K10 01-05	CONTROL ARM	FRONT LOWER W/O BJ RH
UTC06-1932	51350-S5B-A10	HONDA	CIVIC HYBRID 03-	CONTROL ARM	FRONT LOWER W/O BJ RH
UTC06-1933	51350-S9A-A01	HONDA	CRV 02-06	CONTROL ARM	FRONT LOWER W/O BJ RH
UTC06-1934	51350-SAE-T01	HONDA	CITY 03-	CONTROL ARM	FRONT LOWER W/ BJ RH
UTC06-1934	51350-SAE-T01	HONDA	FIT 03-	CONTROL ARM	FRONT LOWER W/ BJ RH
UTC06-1935	51350-SDA-A03 5135	HONDA	ACCORD 03-07	CONTROL ARM	FRONT LOWER W/O BJ RH
UTC06-3930	51350-SDB-A00	HONDA	ACCORD 03-07	CONTROL ARM 6CYL. 0	LOW, RH
UTC06-1936	51350-SHJ-A01	HONDA	ODYSSEY 05~	CONTROL ARM	FRONT LOWER W/ BJ RH
UTC06-1937	51350-SNA-903	HONDA	CIVIC 06-	CONTROL ARM	FRONT LOWER W/O BJ RH
UTC06-1937	51350-SNA-903	HONDA	CIVIC HYBRID 06-	CONTROL ARM	FRONT LOWER W/O BJ RH
UTC06-1938	51350-SOX-A02	HONDA	ODYSSEY 99-04	CONTROL ARM	FRONT LOWER W/ BJ RH
UTC06-1939	51350-SR3-010	HONDA	CIVIC K600 92-95	CONTROL ARM	FRONT LOWER W/O BJ RH
UTC06-1940	51350-SR3-020	HONDA	CIVIC K600 92-95	CONTROL ARM	FRONT LOWER W/O BJ RH
UTC06-3916	51350-SWA-A01	HONDA	CR-V 07-09	CONTROL ARM 07-09	LOW, RH
UTC06-1942	51350-SWA-E01	HONDA	CR-V 07-	CONTROL ARM	FRONT LOWER W/ BJ RH
UTC06-1943	51350-SWA-E11	HONDA	CR-V 07-	CONTROL ARM	FRONT LOWER W/ BJ RH
UTC06-1944	51350-SX8-T01	HONDA	CITY 96-	CONTROL ARM	FRONT LOWER W/ BJ RH
UTC06-4711	51350-TA0-A00	HONDA	ACCORD 08-12	CONTROL ARM	FRONT LOWER W/O BJ RH
UTC06-1945	51350-TAO-A00 5135	HONDA	ACCORD 08-	CONTROL ARM	FRONT LOWER W/O BJ RH
UTC06-1946	51351-SB2-013	HONDA	CIVIC 12V 84~87	CONTROL ARM	FRONT LOWER W/ BJ RH
UTC06-1947	51355-S1A-E00	HONDA	ACCORD K900 98-02(EUROPEAN BUILT)	CONTROL ARM	FRONT LOWER W/O BJ RH
UTC06-4791	51355-S30-000	HONDA	PRELUDE 92-01	CONTROL ARM	FRONT LOWER RH
UTC06-1948	51355-S84-A00	HONDA	ACCORD K900 98-02	CONTROL ARM	FRONT LOWER RH
UTC06-1949	51355-SH3-010	HONDA	CIVIC 16V 88~91	CONTROL ARM	FRONT LOWER W/O BJ RH
UTC06-1951	51355-SM4-040	HONDA	ACCORD K500 90-93	CONTROL ARM	FRONT LOWER RH
UTC06-1952	51355-SV4-000	HONDA	ACCORD K700 94-97	CONTROL ARM	FRONT LOWER W/ BJ RH
UTC06-1952	51355-SV4-000	HONDA	ODYSSEY 95-98	CONTROL ARM	FRONT LOWER RH
UTC06-1953	51360-S01-000	HONDA	DOMANI 96~00(AMERICAN BUILT)	CONTROL ARM	FRONT,LOWER ARM W / O BJ LH
UTC06-1954	51360-S04-G00	HONDA	CIVIC K800 96-00	CONTROL ARM	FRONT LOWER ARM W / O BJ LH
UTC06-1955	51360-S10-A00	HONDA	CRV 97-00	CONTROL ARM	FRONT LOWER W/O BJ LH
UTC06-1956	51360-S3V-A01	HONDA	PILOT 03-05	CONTROL ARM	FRONT,LOWER ARM W / BJ LH
UTC06-4708	51360-S5A-A02	HONDA	CIVIC 02-05	CONTROL ARM	FRONT LOWER W/O BJ LH
UTC06-1957	51360-S5A-A03	HONDA	CIVIC FERIO K10 01-05	CONTROL ARM	FRONT LOWER W/O BJ LH
UTC06-1958	51360-S5B-A10	HONDA	CIVIC HYBRID 03-	CONTROL ARM	FRONT LOWER W/O BJ LH
UTC06-1959	51360-S9A-A01	HONDA	CRV 02-06	CONTROL ARM	FRONT LOWER W/O BJ LH
UTC06-1960	51360-SAE-T01	HONDA	CITY 03-	CONTROL ARM	FRONT LOWER W/ BJ LH
UTC06-1960	51360-SAE-T01	HONDA	FIT 03-	CONTROL ARM	FRONT LOWER W/ BJ LH
UTC06-1961	51360-SDA-A03 5136	HONDA	ACCORD 03-07	CONTROL ARM	FRONT LOWER W/O BJ LH
UTC06-3931	51360-SDB-A00	HONDA	ACCORD 03-07	CONTROL ARM 6CYL. 0	LOW, LH
UTC06-1962	51360-SHJ-A01	HONDA	ODYSSEY 05~	CONTROL ARM	FRONT LOWER W/ BJ LH
UTC06-1963	51360-SNA-903	HONDA	CIVIC 06-	CONTROL ARM	FRONT LOWER W/O BJ LH
UTC06-1963	51360-SNA-903	HONDA	CIVIC HYBRID 06-	CONTROL ARM	FRONT LOWER W/O BJ LH
UTC06-1964	51360-SOX-A02	HONDA	ODYSSEY 99-04	CONTROL ARM	FRONT LOWER W/ BJ LH
UTC06-1965	51360-SR3-010	HONDA	CIVIC K600 92-95	CONTROL ARM	FRONT LOWER W/O BJ LH
UTC06-1966	51360-SR3-020	HONDA	CIVIC K600 92-95	CONTROL ARM	FRONT LOWER W/O BJ LH
UTC06-3915	51360-SWA-A01	HONDA	CR-V 07-09	CONTROL ARM 07-09	LOW, LH
UTC06-4592	51360-SWA-E01	HONDA	CR-V 07-	CONTROL ARM	FRONT LOWER W/ BJ LH
UTC06-1968	51360-SWA-E11	HONDA	CR-V 07-	CONTROL ARM	FRONT LOWER W/ BJ LH
UTC06-1969	51360-SX8-T01	HONDA	CITY 96-	CONTROL ARM	FRONT LOWER W/ BJ LH



UNITEDTEK CORPORATION

Email: utk@seed.net.tw

<u>UT NO.</u>	<u>OEM NO.</u>	<u>MAKE</u>	<u>DESCRIPTION</u>	<u>PART</u>	<u>NOTE</u>
UTC06-4712	51360-TA0-A00	HONDA	ACCORD 08-12	CONTROL ARM	FRONT LOWER W/O BJ LH
UTC06-1970	51360-TAO-A00 5136	HONDA	ACCORD 08-	CONTROL ARM	FRONT LOWER W/O BJ LH
UTC06-1971	51361-SB2-013	HONDA	CIVIC 12V 84~87	CONTROL ARM	FRONT LOWER W/ BJ LH
UTC06-1972	51365-S1A-E00	HONDA	ACCORD K900 98-02(EUROPEN BUILT)	CONTROL ARM	FRONT LOWER W/O BJ LH
UTC06-4792	51365-S30-000	HONDA	PRELUDE 92-01	CONTROL ARM	FRONT LOWER LH
UTC06-1973	51365-S84-A00	HONDA	ACCORD K900 98-02	CONTROL ARM	FRONT LOWER LH
UTC06-1974	51365-SH3-010	HONDA	CIVIC 16V 88~91	CONTROL ARM	FRONT LOWER W/O BJ LH
UTC06-1976	51365-SM4-040	HONDA	ACCORD K500 90-93	CONTROL ARM	FRONT LOWER LH
UTC06-1977	51365-SV4-000	HONDA	ACCORD K700 94-97	CONTROL ARM	FRONT LOWER W/ BJ LH
UTC06-1977	51365-SV4-000	HONDA	ODYSSEY 95-98	CONTROL ARM	FRONT LOWER LH
UTC06-1978	51450-S01-023	HONDA	CIVIC K800 96-00	CONTROL ARM	FRONT UPPER W/ BJ RH
UTC06-1979	51450-S01-023	HONDA	DOMANI 96~00(AMERICAN BUILT)	CONTROL ARM	FRONT,UPPER W /BJ RH
UTC06-1980	51450-S10-020	HONDA	CRV 97-00	CONTROL ARM	FRONT UPPER W/ BJ RH
UTC06-1981	51450-S1A-E11	HONDA	ACCORD K900 98-02(EUROPEN BUILT)	CONTROL ARM	FRONT UPPER W/ BJ RH
UTC06-1982	51450-S84-A01	HONDA	ACCORD K900 98-02	CONTROL ARM	FRONT UPPER W/ BJ RH
UTC06-1983	51450-SDA-A01	HONDA	ACCORD 03-07	CONTROL ARM	FRONT UPPER W/ BJ RH
UTC06-1984	51450-SH3-A03	HONDA	CIVIC 16V 88~91	CONTROL ARM	FRONT UPPER W/ BJ RH
UTC06-1986	51450-SM4-A03	HONDA	ACCORD K500 90-93	CONTROL ARM	FRONT UPPER W/ BJ
UTC06-1988	51450-SR3-013	HONDA	CIVIC K600 92-95	CONTROL ARM	FRONT UPPER W/ BJ RH
UTC06-1989	51450-SV4-000	HONDA	ACCORD K700 94-97	CONTROL ARM	FRONT UPPER W/ BJ RH
UTC06-1989	51450-SV4-000	HONDA	ODYSSEY 95-98	CONTROL ARM	FRONT UPPER W/BJ RH
UTC06-1990	51460-S01-023	HONDA	CIVIC K800 96-00	CONTROL ARM	FRONT UPPER W/ BJ LH
UTC06-1990	51460-S01-023	HONDA	DOMANI 96~00(AMERICAN BUILT)	CONTROL ARM	FRONT,UPPER W /BJ LH
UTC06-1991	51460-S10-020	HONDA	CRV 97-00	CONTROL ARM	FRONT UPPER W/ BJ LH
UTC06-1992	51460-S1A-E11	HONDA	ACCORD K900 98-02(EUROPEN BUILT)	CONTROL ARM	FRONT UPPER W/ BJ LH
UTC06-1993	51460-S84-A01	HONDA	ACCORD K900 98-02	CONTROL ARM	FRONT UPPER W/ BJ LH
UTC06-1994	51460-SDA-A01	HONDA	ACCORD 03-07	CONTROL ARM	FRONT UPPER W/ BJ LH
UTC06-1995	51460-SH3-A03	HONDA	CIVIC 16V 88~91	CONTROL ARM	FRONT UPPER W/ BJ LH
UTC06-1997	51460-SM4-A03	HONDA	ACCORD K500 90-93	CONTROL ARM	FRONT UPPER W/ BJ
UTC06-1999	51460-SR3-013	HONDA	CIVIC K600 92-95	CONTROL ARM	FRONT UPPER W/ BJ LH
UTC06-2000	51460-SV4-000	HONDA	ACCORD K700 94-97	CONTROL ARM	FRONT UPPER W/ BJ LH
UTC06-2000	51460-SV4-000	HONDA	ODYSSEY 95-98	CONTROL ARM	FRONT UPPER W/BJ LH
UTC06-2001	51510-TAO-A03	HONDA	ACCORD 08-	CONTROL ARM	FRONT UPPER W/ BJ RH
UTC06-2002	51520-TAO-A03	HONDA	ACCORD 08-	CONTROL ARM	FRONT UPPER W/ BJ LH
UTC10-4249	51810-TA0-A01	HONDA	ACCORD 08-12	BUSHING	LOW, STRUT
UTC06-2035	52350-S04-000	HONDA	CIVIC K800 96-00	CONTROL ARM	REAR LOWER R/L
UTC06-2035	52350-S04-000	HONDA	DOMANI 96~00(AMERICAN BUILT)	CONTROL ARM	REAR,LOWER R/L
UTC06-2036	52350-S10-A00	HONDA	CRV 97-00	CONTROL ARM	REAR LOWER RH
UTC06-2037	52350-S84-A01	HONDA	ACCORD K900 98-02	CONTROL ARM	REAR,LOWER ARM
UTC06-2038	52350-SDA-A01	HONDA	ACCORD 03-07	CONTROL ARM	REAR, LOWER
UTC06-2039	52350-SH3-A12	HONDA	CIVIC 16V 88~91	CONTROL ARM	REAR LOWER RH
UTC06-2040	52350-SH3-A31	HONDA	CIVIC 16V 88~91	CONTROL ARM	REAR LOWER W/ABS RH
UTC06-2041	52350-SR3-901	HONDA	CIVIC K600 92-95	CONTROL ARM	REAR,LOWER (USA,CANADA BUILT) RH
UTC06-2042	52350-SR3-A10	HONDA	CIVIC K600 92-95	CONTROL ARM	REAR W /O ABS (USA,CANADA BUILT) R/L
UTC06-2043	52360-S10-A00	HONDA	CRV 97-00	CONTROL ARM	REAR LOWER LH



UNITEDTEK CORPORATION

Email: utk@seed.net.tw

<u>UT NO.</u>	<u>OEM NO.</u>	<u>MAKE</u>	<u>DESCRIPTION</u>	<u>PART</u>	<u>NOTE</u>
UTC06-2044	52360-S84-A01	HONDA	ACCORD K900 98-02	CONTROL ARM	REAR R/L
UTC06-4710	52360-SDA-A00	HONDA	ACCORD 03-07	CONTROL ARM	REAR LOWER REAR R/L
UTC06-2045	52360-SDA-A01	HONDA	ACCORD 03-07	CONTROL ARM	REAR, LOWER
UTC06-2046	52360-SH3-A12	HONDA	CIVIC 16V 88~91	CONTROL ARM	REAR LOWER LH
UTC06-2047	52360-SH3-A31	HONDA	CIVIC 16V 88~91	CONTROL ARM	REAR LOWER W/ABS LH
UTC06-2048	52360-SR3-901	HONDA	CIVIC K600 92-95	CONTROL ARM	REAR,LOWER (USA,CANADA BUILT) LH
UTC06-2049	52390-S84-A01	HONDA	ACCORD K900 98-02	CONTROL ARM	REAR UPPER R/L
UTC06-2050	52390-S9A-A11	HONDA	CRV 02-06	CONTROL ARM	REAR UPPER R/L
UTC06-2052	52390-SDA-A01	HONDA	ACCORD 03-07	CONTROL ARM	REAR UPPER
UTC06-2053	52390-SH3-030	HONDA	CIVIC 16V 88~91	CONTROL ARM	REAR UPPER RH
UTC06-2054	52390-SM1-A03	HONDA	ACCORD K500 90-93	CONTROL ARM	REAR,UPPER W/ BJ RH
UTC06-2055	52390-SNA-A00	HONDA	CIVIC 06-	CONTROL ARM	REAR UPPER RH
UTC06-2055	52390-SNA-A00	HONDA	CIVIC HYBRID 06-	CONTROL ARM	REAR UPPER RH
UTC06-2056	52390-SR0-000	HONDA	CIVIC K800 96-00	CONTROL ARM	REAR UPPER RH
UTC06-2056	52390-SR0-000	HONDA	DOMANI 96~00(AMERICAN BUILT)	CONTROL ARM	REAR,UPPER RH
UTC06-2057	52390-SR0-A00	HONDA	CRV 97-00	CONTROL ARM	REAR UPPER RH
UTC06-2058	52390-SR3-A00	HONDA	CIVIC K600 92-95	CONTROL ARM	REAR,UPPER (USA,CANADA BUILT) RH
UTC06-2058	52390-SR3-A00	HONDA	CIVIC K600 92-95	CONTROL ARM	REAR UPPER RH
UTC06-2059	52390-SV4-043	HONDA	ACCORD K700 94-97	CONTROL ARM	REAR UPPER W/ BJ RH
UTC06-2060	52390-SWA-A00	HONDA	CR-V 07-	CONTROL ARM	REAR UPPER R/L
UTC06-2060	52390-SWA-A00	HONDA	CR-V 07-	CONTROL ARM	REAR UPPER R/L
UTC06-2061	52400-SV4-043	HONDA	ACCORD K700 94-97	CONTROL ARM	REAR UPPER W/ BJ LH
UTC06-2062	52400-SH3-030	HONDA	CIVIC 16V 88~91	CONTROL ARM	REAR UPPER LH
UTC06-2063	52400-SM1-A03	HONDA	ACCORD K500 90-93	CONTROL ARM	REAR,UPPER W/ BJ LH
UTC06-2064	52400-SNA-A00	HONDA	CIVIC 06-	CONTROL ARM	REAR UPPER LH
UTC06-2064	52400-SNA-A00	HONDA	CIVIC HYBRID 06-	CONTROL ARM	REAR UPPER LH
UTC06-2065	52400-SR0-000	HONDA	CIVIC K800 96-00	CONTROL ARM	REAR UPPER LH
UTC06-2065	52400-SR0-000	HONDA	DOMANI 96~00 (AMERICAN BUILT)	CONTROL ARM	REAR,UPPER LH
UTC06-2065	52400-SR0-A00	HONDA	CRV 97-00	CONTROL ARM	REAR UPPER LH
UTC06-2066	52400-SR3-A00	HONDA	CIVIC K600 92-95	CONTROL ARM	REAR,UPPER (USA,CANADA BUILT) LH
UTC06-2080	54410-38000 LH	HYUNDAI	SONATA 99-	CONTROL ARM	FRONT UPPER W/ BJ LH
UTC06-2080	54410-38000 LH	HYUNDAI	XG300 01-	CONTROL ARM	FRONT UPPER W/ BJ LH
UTC06-2080	54410-38000 LH	HYUNDAI	XG350 01-	CONTROL ARM	FRONT UPPER W/ BJ LH
UTC06-4286	54410-3F601	HYUNDAI	AZERA 06-11	CONTROL ARM	UP, LH
UTC06-2081	54420-38000 RH	HYUNDAI	SONATA 99-	CONTROL ARM	FRONT UPPER W/ BJ RH
UTC06-2081	54420-38000 RH	HYUNDAI	XG300 01-	CONTROL ARM	FRONT UPPER W/ BJ RH
UTC06-2081	54420-38000 RH	HYUNDAI	XG350 01-	CONTROL ARM	FRONT UPPER W/ BJ RH
UTC06-4287	54420-3F601	HYUNDAI	AZERA 06-11	CONTROL ARM	UP, RH
UTC06-4295	54500-0W000	HYUNDAI	SANTA FE 07-09	CONTROL ARM	LOW, LH
UTC06-2087	54500-17000 LH	HYUNDAI	MATRIX 03-	CONTROL ARM	FRONT LOWER W/ BJ
UTC06-2089	54500-1C000 LH	HYUNDAI	GETZ 04-	CONTROL ARM	FRONT LOWER W/ BJ
UTC06-2092	54500-1E000	HYUNDAI	ACCENT 06-	CONTROL ARM	FRONT LOWER W/O BJ LH
UTC06-4293	54500-1U000	HYUNDAI	SANTA FE 10-	CONTROL ARM	LOW, RH
UTC06-2093	54500-22100	HYUNDAI	ACCENT 95~99	CONTROL ARM	FRONT LOWER W/ BJ LH
UTC06-2094	54500-25000 LH	HYUNDAI	ACCENT 00-05	CONTROL ARM	FRONT LOWER W/ BJ LH
UTC06-3537	54500-29000	HYUNDAI	ELANTRA 96-00	CONTROL ARM	LOW, LH
UTC06-3537	54500-29500	HYUNDAI	ELANTRA 96-00	CONTROL ARM	LOW, LH
UTC06-3900	54500-2D002	HYUNDAI	ELANTRA 01-06	CONTROL ARM	LOW, LH
UTC06-2096	54500-2E000 LH	HYUNDAI	TUCSON 05-	CONTROL ARM	FRONT LOWER W/O BJ LH



UNITEDTEK CORPORATION

Email: utk@seed.net.tw

<u>UT NO.</u>	<u>OEM NO.</u>	<u>MAKE</u>	<u>DESCRIPTION</u>	<u>PART</u>	<u>NOTE</u>
UTC06-4297	54500-2H000	HYUNDAI	ELANTRA 07-10	CONTROL ARM	LOW, LH
UTC06-4297	54500-2H000	HYUNDAI	ELANTRA WAGON 09-12	CONTROL ARM	LOW, LH
UTC06-2100	54500-35110 LH	HYUNDAI	SONATA 89~94	CONTROL ARM	FRONT LOWER W/ BJ LH
UTC06-2101	54500-38000 LH	HYUNDAI	SONATA 99-	CONTROL ARM	FRONT LOWER W/O BJ LH
UTC06-2101	54500-38000 LH	HYUNDAI	XG300 01-	CONTROL ARM	FRONT LOWER W/O BJ LH
UTC06-2101	54500-38000 LH	HYUNDAI	XG350 01-	CONTROL ARM	FRONT LOWER W/O BJ LH
UTC06-4300	54500-3L000	HYUNDAI	AZERA 06-11	CONTROL ARM	W/O BJ, LOW, LH 06-08
UTC06-4301	54500-3L100	HYUNDAI	AZERA 06-11	CONTROL ARM	W/O BJ, LOW, LH 09-11
UTC06-4302	54500-3X000	HYUNDAI	ELANTRA 11-	CONTROL ARM KOREA	BLOW, LH
UTC06-4303	54500-3Y000	HYUNDAI	ELANTRA 11-	CONTROL ARM USA BUI	LOW, LH
UTC06-4304	54500-4D100	HYUNDAI	ENTOURAGE 07-08	CONTROL ARM 2007	LOW, LH
UTC06-4305	54500-4D101	HYUNDAI	ENTOURAGE 07-08	CONTROL ARM 2008	LOW, LH
UTC06-4323	54501-0W000	HYUNDAI	SANTA FE 07-09	CONTROL ARM	LOW, RH
UTC06-2135	54501-17000 RH	HYUNDAI	MATRIX 03-	CONTROL ARM	FRONT LOWER W/ BJ
UTC06-2137	54501-1C000 RH	HYUNDAI	GETZ 04-	CONTROL ARM	FRONT LOWER W/ BJ
UTC06-2138	54501-1E000	HYUNDAI	ACCENT 06-	CONTROL ARM	FRONT LOWER W/O BJ RH
UTC06-4321	54501-1U000	HYUNDAI	SANTA FE 10-	CONTROL ARM	LOW, LH
UTC06-2139	54501-22100	HYUNDAI	ACCENT 95~99	CONTROL ARM	FRONT LOWER W/ BJ RH
UTC06-2140	54501-25000 RH	HYUNDAI	ACCENT 00-05	CONTROL ARM	FRONT LOWER W/ BJ RH
UTC06-3721	54501-26000	HYUNDAI	SANTA FE 01-06	CONTROL ARM	LOW, LH
UTC06-3538	54501-29000	HYUNDAI	ELANTRA 96-00	CONTROL ARM	LOW, RH
UTC06-3538	54501-29500	HYUNDAI	ELANTRA 96-00	CONTROL ARM	LOW, RH
UTC06-3899	54501-2D002	HYUNDAI	ELANTRA 01-06	CONTROL ARM	LOW, RH
UTC06-2142	54501-2E000 RH	HYUNDAI	TUCSON 05-	CONTROL ARM	FRONT LOWER W/O BJ RH
UTC06-4325	54501-2H000	HYUNDAI	ELANTRA 07-10	CONTROL ARM	LOW, RH
UTC06-4326	54501-2H000	HYUNDAI	ELANTRA WAGON 09-12	CONTROL ARM	LOW, RH
UTC06-2146	54501-35110 RH	HYUNDAI	SONATA 89~94	CONTROL ARM	FRONT LOWER W/ BJ RH
UTC06-2147	54501-38000 RH	HYUNDAI	SONATA 99-	CONTROL ARM	FRONT LOWER W/O BJ RH
UTC06-2147	54501-38000 RH	HYUNDAI	XG300 01-	CONTROL ARM	FRONT LOWER W/O BJ RH
UTC06-2147	54501-38000 RH	HYUNDAI	XG350 01-	CONTROL ARM	FRONT LOWER W/O BJ RH
UTC06-4329	54501-3L000	HYUNDAI	AZERA 06-11	CONTROL ARM	W/O BJ, LOW, RH 06-08
UTC06-4330	54501-3L100	HYUNDAI	AZERA 06-11	CONTROL ARM	W/O BJ, LOW, RH 09-11
UTC06-4331	54501-3X000	HYUNDAI	ELANTRA 11-	CONTROL ARM KOREA	BLOW, RH
UTC06-4332	54501-3Y000	HYUNDAI	ELANTRA 11-	CONTROL ARM USA BUI	LOW, RH
UTC06-4333	54501-4D100	HYUNDAI	ENTOURAGE 07-08	CONTROL ARM 2007	LOW, RH
UTC06-4334	54501-4D101	HYUNDAI	ENTOURAGE 07-08	CONTROL ARM 2008	LOW, RH
UTC06-3720	54502-26000	HYUNDAI	SANTA FE 01-06	CONTROL ARM	LOW, RH
UTC06-2082	54468-CD00C	INFINITY	G35 03-	CONTROL ARM	FRONT LOWER W/ BJ RH
UTC06-2083	54469-CD00C	INFINITY	G35 03-	CONTROL ARM	FRONT LOWER W/ BJ LH
UTC06-2086	54500-0W000	INFINITY	QX4 97-03	CONTROL ARM	FRONT, LOWER W/ O BJ RH
UTC06-2090	54500-1CA0A	INFINITY	FX35 09-	CONTROL ARM	FRONT LOWER W/ BJ LH
UTC06-2091	54500-1CA0A	INFINITY	FX35 09-	CONTROL ARM	FRONT LOWER W/ BJ RH
UTC06-2098	54500-2J011	INFINITY	G 99-	CONTROL ARM	FRONT LOWER W/ BJ RH
UTC06-2102	54500-41U01	INFINITY	I30 96~99	CONTROL ARM	FRONT LOWER W/ BJ RH
UTC06-2108	54500-50J25	INFINITY	G 91~96	CONTROL ARM	FRONT LOWER W/ BJ RH
UTC06-2119	54500-AM601	INFINITY	G35 03-	CONTROL ARM	FRONT LOWER W/O BJ RH
UTC06-2121	54500-CG200	INFINITY	FX35 03-08	CONTROL ARM	FRONT LOWER W/ BJ RH
UTC06-2121	54500-CG200	INFINITY	FX45 03-08	CONTROL ARM	FRONT LOWER W/ BJ RH
UTC06-2123	54500-EG00A	INFINITY	M35 06-	CONTROL ARM	FRONT LOWER W/ BJ RH
UTC06-2123	54500-EG00A	INFINITY	M45 06-	CONTROL ARM	FRONT LOWER W/ BJ RH
UTC06-2128	54500-JK500	INFINITY	G35 08-	CONTROL ARM	FRONT LOWER W/ BJ RH
UTC06-2129	54500-JL00C	INFINITY	G37 08-	CONTROL ARM	FRONT LOWER W/ BJ RH
UTC06-2130	54500-JL01A	INFINITY	EX35 08-	CONTROL ARM	FRONT LOWER W/ BJ RH
UTC06-2134	54501-0W000	INFINITY	QX4 97-03	CONTROL ARM	FRONT, LOWER W/ O BJ LH



UNITEDTEK CORPORATION

Email: utk@seed.net.tw

<u>UT NO.</u>	<u>OEM NO.</u>	<u>MAKE</u>	<u>DESCRIPTION</u>	<u>PART</u>	<u>NOTE</u>
UTC06-2144	54501-2J011	INFINITY	G 99-	CONTROL ARM	FRONT LOWER W/ BJ LH
UTC06-2148	54501-41U01	INFINITY	I30 96~99	CONTROL ARM	FRONT LOWER W/ BJ LH
UTC06-2154	54501-50J25	INFINITY	G 91~96	CONTROL ARM	FRONT LOWER W/ BJ LH
UTC06-2165	54501-AM601	INFINITY	G35 03-	CONTROL ARM	FRONT LOWER W/O BJ LH
UTC06-2167	54501-CG200	INFINITY	FX35 03-08	CONTROL ARM	FRONT LOWER W/ BJ LH
UTC06-2167	54501-CG200	INFINITY	FX45 03-08	CONTROL ARM	FRONT LOWER W/ BJ LH
UTC06-2169	54501-EG00A	INFINITY	M35 06-	CONTROL ARM	FRONT LOWER W/ BJ LH
UTC06-2169	54501-EG00A	INFINITY	M45 06-	CONTROL ARM	FRONT LOWER W/ BJ LH
UTC06-2174	54501-JK500	INFINITY	G35 08-	CONTROL ARM	FRONT LOWER W/ BJ LH
UTC06-2175	54501-JL00C	INFINITY	G37 08-	CONTROL ARM	FRONT LOWER W/ BJ LH
UTC06-2176	54501-JL01A	INFINITY	EX35 08-	CONTROL ARM	FRONT LOWER W/ BJ LH
UTC06-2182	54524-2J001	INFINITY	G 99-	CONTROL ARM	FRONT UPPER W/ BUSHINGS RH
UTC06-2182	54524-2J001	INFINITY	G 91~96	CONTROL ARM	FRONT UPPER W/ BUSHING RH
UTC06-2186	54524-AL500	INFINITY	G35 03-	CONTROL ARM	FRONT UPPER W/ BJ RH
UTC06-2189	54524-EG000	INFINITY	M35 06-	CONTROL ARM	FRONT UPPER W/ BJ RH
UTC06-2189	54524-EG000	INFINITY	M45 06-	CONTROL ARM	FRONT UPPER W/ BJ RH
UTC06-2190	54524-JK000	INFINITY	FX35 09-	CONTROL ARM	FRONT UPPER W/ BJ RH
UTC06-2190	54524-JK000	INFINITY	G35 08-	CONTROL ARM	FRONT UPPER W/ BJ RH
UTC06-2191	54524-JL00B	INFINITY	EX35 08-	CONTROL ARM	FRONT UPPER W/ BJ RH
UTC06-2193	54525-2J001	INFINITY	G 99-	CONTROL ARM	FRONT UPPER W/ BUSHINGS LH
UTC06-2193	54525-2J001	INFINITY	G 91~96	CONTROL ARM	FRONT UPPER W/ BUSHING LH
UTC06-2196	54525-AL500	INFINITY	G35 03-	CONTROL ARM	FRONT UPPER W/ BJ LH
UTC06-2199	54525-EG000	INFINITY	M35 06-	CONTROL ARM	FRONT UPPER W/ BJ LH
UTC06-2199	54525-EG000	INFINITY	M45 06-	CONTROL ARM	FRONT UPPER W/ BJ LH
UTC06-2200	54525-JK000	INFINITY	FX35 09-	CONTROL ARM	FRONT UPPER W/ BJ LH
UTC06-2200	54525-JK000	INFINITY	G35 08-	CONTROL ARM	FRONT UPPER W/ BJ LH
UTC06-2201	54525-JL00B	INFINITY	EX35 08-	CONTROL ARM	FRONT UPPER W/ BJ LH
UTC06-2205	55501-1BA0A	INFINITY	EX35 08-	CONTROL ARM	REAR UPPER W/ BALL JOINT RH
UTC06-2206	55501-1CA0A	INFINITY	FX35 09-	CONTROL ARM	REAR UPPER W/ BALL JOINT RH
UTC06-2208	55501-AL50E	INFINITY	G35 03-	CONTROL ARM	REAR UPPER W/ BJ RH
UTC06-2209	55501-CG200	INFINITY	FX35 03-08	CONTROL ARM	REAR UPPER W/ BALL JOINT RH
UTC06-2209	55501-CG200	INFINITY	FX45 03-08	CONTROL ARM	REAR UPPER ARM W/ BJ RH
UTC06-2210	55501-EG00A	INFINITY	M35 06-	CONTROL ARM	REAR,UPPER W/ BALL JOINT RH
UTC06-2210	55501-EG00A	INFINITY	M45 06-	CONTROL ARM	REAR,UPPER W/ BALL JOINT RH
UTC06-2212	55501-JK02A	INFINITY	G35 08-	CONTROL ARM	REAR UPPER W/ BJ RH
UTC06-2213	55501-JL01A	INFINITY	G37 08-	CONTROL ARM	REAR UPPER W/ BJ RH
UTC06-2216	55502-1BA0A	INFINITY	EX35 08-	CONTROL ARM	REAR UPPER W/ BALL JOINT LH
UTC06-2217	55502-1CA0A	INFINITY	FX35 09-	CONTROL ARM	REAR UPPER W/ BALL JOINT LH
UTC06-2219	55502-AL50E	INFINITY	G35 03-	CONTROL ARM	REAR UPPER W/ BJ LH
UTC06-2220	55502-CG200	INFINITY	FX35 03-08	CONTROL ARM	REAR UPPER W/ BALL JOINT LH
UTC06-2220	55502-CG200	INFINITY	FX45 03-08	CONTROL ARM	REAR UPPER ARM W/ BJ LH



UNITEDTEK CORPORATION

Email: utk@seed.net.tw

<u>UT NO.</u>	<u>OEM NO.</u>	<u>MAKE</u>	<u>DESCRIPTION</u>	<u>PART</u>	<u>NOTE</u>
UTC06-2221	55502-EG00A	INFINITY	M35 06-	CONTROL ARM	REAR,UPPER W/ BALL JOINT LH
UTC06-2221	55502-EG00A	INFINITY	M45 06-	CONTROL ARM	REAR,UPPER W/ BALL JOINT LH
UTC06-2223	55502-JK02A	INFINITY	G35 08-	CONTROL ARM	REAR UPPER W/ BJ LH
UTC06-2224	55502-JL01A	INFINITY	G37 08-	CONTROL ARM	REAR UPPER W/ BJ LH
UTC06-1345	8-15858-683-0	ISUZU	ASCENDER 03-08	CONTROL ARM	UP, LH
UTC06-1346	8-15858-683-0	ISUZU	ASCENDER 03-08	CONTROL ARM	UP, RH
UTC06-4453	8-19133-553-0	ISUZU	ASCENDER 03	CONTROL ARM W/O BJ	LOW, LH
UTC06-4454	8-19133-554-0	ISUZU	ASCENDER 03	CONTROL ARM W/O BJ	LOW, RH
UTC06-4455	8-19133-555-0	ISUZU	ASCENDER 04-08	CONTROL ARM W/O BJ	LOW, LH
UTC06-4456	8-19133-556-0	ISUZU	ASCENDER 04-08	CONTROL ARM W/O BJ	LOW, RH
UTC06-1345	8-25786-774-0	ISUZU	ASCENDER 03-08	CONTROL ARM	UP, LH
UTC06-1346	8-25786-775-0	ISUZU	ASCENDER 03-08	CONTROL ARM	UP, RH
UTC06-1294	0K011-34-200A	KIA	SPORTAGE 95-02	CONTROL ARM	UP, R/L
UTC10-1450	0K011-34-380A	KIA	SPORTAGE 95-02	BUSHING	FOR UPPER CONTROL ARM
UTC06-1327	0K30B-34-300B	KIA	RIO 01-02	CONTROL ARM	LOW, RH
UTC06-1328	0K30B-34-350B	KIA	RIO 01-02	CONTROL ARM	LOW, LH
UTC06-3560	0K552-34-300B	KIA	SEDONA 02-05	CONTROL ARM	LOW, RH
UTC06-3559	0K552-34-350B	KIA	SEDONA 02-05	CONTROL ARM	LOW, LH
UTC06-3937	54500-1E100	KIA	RIO 06-11	CONTROL ARM W/O BJ,	LOW, LH
UTC06-1329	54500-FD000	KIA	RIO 03-04	CONTROL ARM	LOW, RH
UTC06-3936	54501-1E100	KIA	RIO 06-11	CONTROL ARM W/O BJ,	LOW, RH
UTC06-1330	54501-FD000	KIA	RIO 03-04	CONTROL ARM	LOW, LH
UTC06-4142	48068-0E010	LEXUS	RX330 04-06	CONTROL ARM W/O BJ	LOW, RH
UTC06-4142	48068-0E010	LEXUS	RX350 07-09	CONTROL ARM W/O BJ	LOW, RH
UTC06-4144	48068-0T011	LEXUS	RX 10-11	CONTROL ARM W/O BJ	LOW, RH
UTC06-4145	48068-12300	LEXUS	HS250H 10-11	CONTROL ARM W/O BJ	LOW, RH
UTC06-3533	48068-33030	LEXUS	ES300 97-01	CONTROL ARM W/O BJ	LOW, RH
UTC06-4152	48068-48010	LEXUS	ES300 97-01	CONTROL ARM W/O BJ	LOW, RH
UTC06-4152	48068-48010	LEXUS	RX300 99-03	CONTROL ARM W/O BJ	LOW, RH
UTC06-4153	48068-48041	LEXUS	RX 10-11	CONTROL ARM W/O BJ	LOW, RH
UTC06-4165	48069-0E010	LEXUS	ES300 02	CONTROL ARM W/O BJ	LOW, LH
UTC06-4165	48069-0E010	LEXUS	RX330 04-06	CONTROL ARM W/O BJ	LOW, LH
UTC06-4165	48069-0E010	LEXUS	RX350 07-09	CONTROL ARM W/O BJ	LOW, LH
UTC06-4165	48069-0E010	LEXUS	RX400H 06-08	CONTROL ARM W/O BJ	LOW, LH
UTC06-4167	48069-0T011	LEXUS	RX 10-11	CONTROL ARM W/O BJ	LOW, LH
UTC06-4168	48069-12300	LEXUS	HS250H 10-11	CONTROL ARM W/O BJ	LOW, LH
UTC06-3534	48069-33030	LEXUS	ES300 97-01	CONTROL ARM W/O BJ	LOW, LH
UTC06-4175	48069-48010	LEXUS	ES300 97-01	CONTROL ARM W/O BJ	LOW, LH
UTC06-4175	48069-48010	LEXUS	RX300 99-03	CONTROL ARM W/O BJ	LOW, LH
UTC06-4176	48069-48041	LEXUS	RX 10-11	CONTROL ARM W/O BJ	LOW, LH
UTC06-4191	48610-39085	LEXUS	GS300 98-05	CONTROL ARM	UP, RH
UTC06-4191	48610-39085	LEXUS	GS400 98-00	CONTROL ARM	UP, RH
UTC06-4191	48610-39085	LEXUS	GS430 01-05	CONTROL ARM	UP, RH
UTC06-4191	48610-39085	LEXUS	SC430 02-10	CONTROL ARM	UP, RH
UTC06-4192	48610-39135	LEXUS	GS300 06	CONTROL ARM	UP, R/L
UTC06-4192	48610-39135	LEXUS	GS350 07-11	CONTROL ARM	UP, R/L
UTC06-4192	48610-39135	LEXUS	IS250 06-13	CONTROL ARM	UP, R/L
UTC06-4192	48610-39135	LEXUS	IS350 11-13	CONTROL ARM	UP, R/L
UTC06-1830	48610-59045	LEXUS	LS430 01-	CONTROL ARM	FRONT UPPER W/ BJ
UTC06-4195	48630-39055	LEXUS	GS300 98-05	CONTROL ARM	UP, LH
UTC06-4195	48630-39055	LEXUS	GS400 98-00	CONTROL ARM	UP, LH
UTC06-4195	48630-39055	LEXUS	GS430 01-05	CONTROL ARM	UP, LH



UNITEDTEK CORPORATION

Email: utk@seed.net.tw

<u>UT NO.</u>	<u>OEM NO.</u>	<u>MAKE</u>	<u>DESCRIPTION</u>	<u>PART</u>	<u>NOTE</u>
UTC06-4195	48630-39055	LEXUS	SC430 02-10	CONTROL ARM	UP, LH
UTC06-1833	48630-59045	LEXUS	LS430 01-	CONTROL ARM	FRONT UPPER W/ BJ
UTC06-1294	0K011-34-200A	MAZDA	323 93-	CONTROL ARM	UP
UTC06-1301	1F71-34-211	MAZDA	B4000 98-08	CONTROL ARM	UP
UTC06-1303	1F71-35-211	MAZDA	B4000 98-08	CONTROL ARM	UP
UTC06-1301	6L5Z-3084BA	MAZDA	B2300 01-09	CONTROL ARM	UP
UTC06-1301	6L5Z-3084BA	MAZDA	B2500 98-01	CONTROL ARM	UP
UTC06-1301	6L5Z-3084BA	MAZDA	B3000 98-07	CONTROL ARM	UP
UTC06-1303	6L5Z-3085BA	MAZDA	B2300 01-09	CONTROL ARM	UP
UTC06-1303	6L5Z-3085BA	MAZDA	B2500 98-01	CONTROL ARM	UP
UTC06-1303	6L5Z-3085BA	MAZDA	B3000 98-07	CONTROL ARM	UP
UTC06-2301	B01A-34-300E	MAZDA	PROTÉGÉ 97-98	CONTROL ARM	FRONT LOWER W/O B J RH
UTC06-2303	B01A-34-350E	MAZDA	PROTÉGÉ 97-98	CONTROL ARM	FRONT LOWER W/O B J LH
UTC06-2304	B092-34-310A	MAZDA	FAMILIA	CONTROL ARM	FRONT LOWER W/O BJ RH
UTC06-2304	B092-34-310A	MAZDA	323	CONTROL ARM	FRONT LOWER W/O BJ RH
UTC06-2305	B092-34-360A	MAZDA	FAMILIA	CONTROL ARM	FRONT LOWER W/O BJ LH
UTC06-2305	B092-34-360A	MAZDA	323	CONTROL ARM	FRONT LOWER W/O BJ LH
UTC06-2306	B25D-34-300B	MAZDA	PROTÉGÉ 99-00	CONTROL ARM	FRONT LOWER W/ BJ RH
UTC06-2307	B25D-34-350B	MAZDA	PROTÉGÉ 99-00	CONTROL ARM	FRONT LOWER W/ BJ LH
UTC06-4514	B28V-34-300B	MAZDA	PROTÉGÉ 01-03	CONTROL ARM	LOW, RH
UTC06-4515	B28V-34-350B	MAZDA	PROTÉGÉ 01-03	CONTROL ARM	LOW, LH
UTC06-2308	B32H-34-300	MAZDA	3 03-	CONTROL ARM	FRONT LOWER W/ BJ RH
UTC06-2309	B32H-34-300A	MAZDA	5 05-	CONTROL ARM	FRONT LOWER W/ BJ R/L
UTC06-2310	B32H-34-350	MAZDA	3 03-	CONTROL ARM	FRONT LOWER W/ BJ LH
UTC06-2311	B32H-34-350A	MAZDA	5 05-	CONTROL ARM	FRONT LOWER W/ BJ R/L
UTC06-2312	B455-34-300E	MAZDA	FAMILIA	CONTROL ARM	FRONT LOWER W/O BJ RH
UTC06-2312	B455-34-300E	MAZDA	323	CONTROL ARM	FRONT LOWER W/O BJ RH
UTC06-2312	B455-34-350E	MAZDA	FAMILIA	CONTROL ARM	FRONT LOWER W/O BJ LH
UTC06-2312	B455-34-350E	MAZDA	323	CONTROL ARM	FRONT LOWER W/O BJ LH
UTC06-2313	BBM2-34-300	MAZDA	3 10-	CONTROL ARM	FRONT LOWER W/ BJ RH
UTC06-2314	BBM2-34-300A	MAZDA	3 10-	CONTROL ARM	LOW, RH
UTC06-2314	BBM2-34-350	MAZDA	3 10-	CONTROL ARM	FRONT LOWER W/ BJ LH
UTC06-2313	BBM2-34-350A	MAZDA	3 10-	CONTROL ARM	LOW, LH
UTC06-4531	D651-34-300D	MAZDA	2 11-	CONTROL ARM	LOW, RH
UTC06-4532	D651-34-350E	MAZDA	2 11-	CONTROL ARM	LOW, LH
UTC06-2325	EC01-28-500E	MAZDA	TRIBUTE 01-06	CONTROL ARM	REAR,LOWER RH
UTC06-2326	EC01-28-550E	MAZDA	TRIBUTE 01-06	CONTROL ARM	REAR,LOWER LH
UTC06-2327	EC01-28-600C	MAZDA	TRIBUTE 01-06	CONTROL ARM	REAR,UPPER RH
UTC06-2328	EC01-28-650C	MAZDA	TRIBUTE 01-06	CONTROL ARM	REAR,UPPER LH
UTC06-2329	EC01-34-300F	MAZDA	TRIBUTE 01-06	CONTROL ARM	FRONT LOWER W/ BJ RH
UTC06-2330	EC01-34-350F	MAZDA	TRIBUTE 01-06	CONTROL ARM	FRONT LOWER W/ BJ LH
UTC06-3924	EH44-34-300	MAZDA	CX-7 07-11	CONTROL ARM	LOW, RH
UTC06-3925	EH44-34-350	MAZDA	CX-7 07-11	CONTROL ARM	LOW, LH
UTC06-2342	G030-34-300F	MAZDA	626 83-87	CONTROL ARM	FRONT LOWER W/ BJ RH
UTC06-2342	G030-34-300F	MAZDA	CAPELLA 83-87	CONTROL ARM	FRONT LOWER W/ BJ RH
UTC06-2343	G030-34-350F	MAZDA	626 83-87	CONTROL ARM	FRONT LOWER W/ BJ LH
UTC06-2343	G030-34-350F	MAZDA	CAPELLA 83-87	CONTROL ARM	FRONT LOWER W/ BJ LH
UTC06-4547	G26A-28-C10	MAZDA	6 03-08	CONTROL ARM 03-04	UP, REAR R/L
UTC06-2344	GA2A-34-300A	MAZDA	MX-6 93-97	CONTROL ARM	FRONT LOWER W/ BJ RH
UTC06-2345	GA2A-34-350A	MAZDA	MX-6 93-97	CONTROL ARM	FRONT LOWER W/ BJ LH
UTC06-2346	GE4T-34-300C	MAZDA	626 98-	CONTROL ARM	FRONT LOWER W/ BJ RH
UTC06-2346	GE4T-34-300C	MAZDA	CAPELLA 98-02	CONTROL ARM	FRONT LOWER W/ BJ RH
UTC06-2347	GE4T-34-350C	MAZDA	626 98-	CONTROL ARM	FRONT LOWER W/ BJ LH
UTC06-2347	GE4T-34-350C	MAZDA	CAPELLA 98-02	CONTROL ARM	FRONT LOWER W/ BJ LH



UNITEDTEK CORPORATION

Email: utk@seed.net.tw

<u>UT NO.</u>	<u>OEM NO.</u>	<u>MAKE</u>	<u>DESCRIPTION</u>	<u>PART</u>	<u>NOTE</u>
UTC06-2348	GJ22-34-300A	MAZDA	626 88-92	CONTROL ARM	FRONT LOWER W/ BJ RH
UTC06-2348	GJ22-34-300A	MAZDA	CAPELLA 88-92	CONTROL ARM	FRONT LOWER W/ BJ RH
UTC06-2349	GJ22-34-350A	MAZDA	626 88-92	CONTROL ARM	FRONT LOWER W/ BJ LH
UTC06-2349	GJ22-34-350A	MAZDA	CAPELLA 88-92	CONTROL ARM	FRONT LOWER W/ BJ LH
UTC06-2350	GJ6A-34-200B	MAZDA	6 03-08	CONTROL ARM	FRONT UPPER W/ BJ RH
UTC06-2351	GJ6A-34-250B	MAZDA	6 03-08	CONTROL ARM	FRONT UPPER W/ BJ LH
UTC06-2352	GJ6A-34-300B	MAZDA	6 03-08	CONTROL ARM	FRONT LOWER W/ BJ R/L
UTC06-3086	GJ6A-34-300E	MAZDA	6 03-07	CONTROL ARM	FRONT LOWER FRONT R/L (12MM)
UTC06-2353	GJ6A-34-J00C	MAZDA	6 03-08	CONTROL ARM	FRONT LOWER W/ BJ RH
UTC06-2354	GJ6A-34-J50C	MAZDA	6 03-08	CONTROL ARM	FRONT LOWER W/ BJ LH
UTC10-4551	GP9A-28-C10	MAZDA	6 05-08	CONTROL ARM	UP, REAR R/L
UTC06-2355	GS1D-34-250A	MAZDA	6 09-	CONTROL ARM	FRONT UPPER W/ BJ LH
UTC06-2356	GS1D-34-300H	MAZDA	6 09-	CONTROL ARM	FRONT LOWER W/ BJ RH
UTC06-2357	GS1D-34-300K	MAZDA	6 09-	CONTROL ARM	FRONT UPPER W/ BJ RH
UTC06-2358	GS1D-34-350H	MAZDA	6 09-	CONTROL ARM	FRONT LOWER W/ BJ LH
UTC06-2359	H380-34-300A	MAZDA	929 92-	CONTROL ARM	FRONT LOWER W/ BJ RH
UTC06-2360	H380-34-350A	MAZDA	929 92-	CONTROL ARM	FRONT LOWER W/ BJ LH
UTC06-1305	K80068	MAZDA	B2500 99-01	CONTROL ARM	UP
UTC06-1305	K80068	MAZDA	B3000 98-07	CONTROL ARM	UP
UTC06-1305	K80068	MAZDA	B4000 98-09	CONTROL ARM	UP
UTC10-1436	K8704	MAZDA	B2300 03-04	BUSHING	FOR UPPER CONTROL ARM
UTC10-1436	K8704	MAZDA	B3000 98-04	BUSHING	FOR UPPER CONTROL ARM
UTC10-1436	K8704	MAZDA	B4000 98-04	BUSHING	FOR UPPER CONTROL ARM
UTC06-1283	K8708T	MAZDA	B2500 99-01	CONTROL ARM	UP
UTC06-1283	K8708T	MAZDA	B3000 98-07	CONTROL ARM	UP
UTC06-1283	K8708T	MAZDA	B4000 98-09	CONTROL ARM	UP
UTC06-1284	K8710T	MAZDA	B2500 99-01	CONTROL ARM	UP
UTC06-1284	K8710T	MAZDA	B3000 98-01	CONTROL ARM	UP
UTC06-1284	K8710T	MAZDA	B4000 98-01	CONTROL ARM	UP
UTC06-2390	LB82-34-300	MAZDA	MPV 89-98	CONTROL ARM	FRONT LOWER W/ BJ R/L
UTC06-2391	LC62-34-300C	MAZDA	MPV 00-	CONTROL ARM	FRONT LOWER W/ BJ RH
UTC06-2392	LC62-34-350C	MAZDA	MPV 00-	CONTROL ARM	FRONT LOWER W/ BJ LH
UTC06-4573	NE51-34-300D	MAZDA	MX-5 MIATA 06-11	CONTROL ARM	LOW, RH
UTC06-4574	NE51-34-350D	MAZDA	MX-5 MIATA 06-11	CONTROL ARM	LOW, LH
UTC06-4575	NH42-34-200	MAZDA	MX-5 MIATA 06-11	CONTROL ARM	UP, RH
UTC06-4576	NH42-34-250	MAZDA	MX-5 MIATA 06-11	CONTROL ARM	UP, LH
UTC06-2466	S083-49-200A	MAZDA	BONGO 80-84	CONTROL ARM	FRONT,UPPER W/ O BJ RH
UTC06-2467	S083-49-250A	MAZDA	BONGO 80-84	CONTROL ARM	FRONT,UPPER W/ O BJ LH
UTC06-2468	S083-49-300B	MAZDA	BONGO 80-84	CONTROL ARM	FRONT LOWER W/O BJ RH
UTC06-2469	S083-49-350B	MAZDA	BONGO 80-84	CONTROL ARM	FRONT LOWER W/O BJ LH
UTC06-4581	TD11-34-300B	MAZDA	CX-9 07-11	CONTROL ARM	LOW, RH
UTC06-4582	TE69-34-350	MAZDA	CX-9 07-11	CONTROL ARM	LOW, LH
UTC06-3725	ZZC1-34-310	MAZDA	TRIBUTE 08-11	CONTROL ARM	LOW, RH
UTC06-3726	ZZC1-34-320	MAZDA	TRIBUTE 08-11	CONTROL ARM	LOW, LH
UTC06-1683	4010A019 LH	MAZDA	ZINGER 05-	CONTROL ARM	FRONT UPPER W/O BJ LH
UTC06-1684	4010A020 RH	MAZDA	ZINGER 05-	CONTROL ARM	FRONT UPPER W/O BJ RH
UTC06-4050	4010A037	MAZDA	MONTERO 01-06	CONTROL ARM	UP, LH
UTC06-4051	4010A038	MAZDA	MONTERO 01-06	CONTROL ARM	UP, RH
UTC06-1685	4013A106 LH	MAZDA	ZINGER 05-	CONTROL ARM	FRONT LOWER W/O BJ LH
UTC06-1686	4013A107 RH	MAZDA	ZINGER 05-	CONTROL ARM	FRONT LOWER W/O BJ RH
UTC06-4052	4013A181	MAZDA	LANCER EVOLUTION 08-11	CONTROL ARM	LOW, LH
UTC06-4053	4013A182	MAZDA	LANCER EVOLUTION 08-11	CONTROL ARM	LOW, RH
UTC06-3906	4013A273	MAZDA	LANCER 02-07	CONTROL ARM	LOW, LH



UNITEDTEK CORPORATION

Email: utk@seed.net.tw

<u>UT NO.</u>	<u>OEM NO.</u>	<u>MAKE</u>	<u>DESCRIPTION</u>	<u>PART</u>	<u>NOTE</u>
UTC06-3901	4013A274	MITSUBISHI	LANCER 02-07	CONTROL ARM	LOW, RH
UTC06-4054	4013A279	MITSUBISHI	LANCER 08-11	CONTROL ARM	LOW, LH
UTC06-4055	4013A280	MITSUBISHI	LANCER 08-11	CONTROL ARM	LOW, RH
UTC06-4056	4013A281	MITSUBISHI	OUTLANDER 07-11	CONTROL ARM	LOW, LH
UTC06-4057	4013A282	MITSUBISHI	OUTLANDER 07-11	CONTROL ARM	LOW, RH
UTC06-1338	52855100AD	MITSUBISHI	RAIDER 06-09	CONTROL ARM	UP
UTC06-2320	CW731604 LH	MITSUBISHI	VERYCA 99-	CONTROL ARM	FRONT LOWER W/ BJ LH 2WD
UTC06-2321	CW731605 RH	MITSUBISHI	VERYCA 99-	CONTROL ARM	FRONT LOWER W/ BJ RH 2WD
UTC10-1427	K7473	MITSUBISHI	RAIDER 06-09	BUSHING	FOR UPPER CONTROL ARM
UTC06-2395	MB109343	MITSUBISHI	DELICA L300 80~86	CONTROL ARM	FRONT LOWER W/O BJ R/L
UTC06-4596	MB109512	MITSUBISHI	DELICA L200 83~94	CONTROL ARM	FRONT LOWER W/O BJ LH
UTC06-4595	MB109513	MITSUBISHI	DELICA L200 83~94	CONTROL ARM	FRONT LOWER W/O BJ RH
UTC06-2397	MB325251	MITSUBISHI	ECLIPSE 96~99	CONTROL ARM	FRONT LOWER W/ BJ LH
UTC06-2397	MB325251 LH MB912	MITSUBISHI	GALANT 94~99	CONTROL ARM	FRONT LOWER W/ BJ LH
UTC06-2398	MB325252	MITSUBISHI	ECLIPSE 96~99	CONTROL ARM	FRONT LOWER W/ BJ RH
UTC06-2398	MB325252 RH MB912	MITSUBISHI	GALANT 94~99	CONTROL ARM	FRONT LOWER W/ BJ RH
UTC06-2401	MB349475 R/L MB109	MITSUBISHI	DELICA L300 PICK UP 86	CONTROL ARM	FRONT,UPPER W/O SHAFT R/L
UTC06-2402	MB349943 LH	MITSUBISHI	DELICA L300 PICK UP 86	CONTROL ARM	FRONT LOWER W/O BJ LH
UTC06-2403	MB349944 RH	MITSUBISHI	DELICA L300 PICK UP 86	CONTROL ARM	FRONT LOWER W/O BJ RH
UTC06-2404	MB376527	MITSUBISHI	SPACE GEAR 96	CONTROL ARM	FRONT UPPER W/ BJ LH 4WD
UTC06-2405	MB376528	MITSUBISHI	SPACE GEAR 96	CONTROL ARM	FRONT UPPER W/ BJ RH 4WD
UTC06-2406	MB518205	MITSUBISHI	ECLIPSE 90~94	CONTROL ARM	FRONT LOWER W/ BJ LH (1.8L)
UTC06-2406	MB518205 LH	MITSUBISHI	GALANT 89~93	CONTROL ARM	FRONT LOWER W/ BJ LH
UTC06-2407	MB518206	MITSUBISHI	ECLIPSE 90~94	CONTROL ARM	FRONT LOWER W/ BJ RH (1.8L)
UTC06-2407	MB518206 RH	MITSUBISHI	GALANT 89~93	CONTROL ARM	FRONT LOWER W/ BJ RH
UTC06-4594	MB527159	MITSUBISHI	DELICA L200 83~94	CONTROL ARM	FRONT UPPER W/ BJ LH
UTC06-2408	MB527383 LH MB430	MITSUBISHI	DELICA NEW L300 87-	CONTROL ARM	FRONT LOWER W/ BJ LH
UTC06-2409	MB527384 RH MB430	MITSUBISHI	DELICA NEW L300 87-	CONTROL ARM	FRONT LOWER W/ BJ RH
UTC06-2410	MB573094	MITSUBISHI	ECLIPSE 90~94	CONTROL ARM	FRONT LOWER W/ BJ RH (2.0L)
UTC06-2410	MB573094 RH	MITSUBISHI	GALANT 89~93	CONTROL ARM	FRONT LOWER W/ BJ RH
UTC06-2411	MB573096	MITSUBISHI	ECLIPSE 90~94	CONTROL ARM	FRONT LOWER W/ BJ LH (2.0L)
UTC06-2411	MB573096 RH	MITSUBISHI	GALANT 89~93	CONTROL ARM	FRONT LOWER W/ BJ LH
UTC06-2412	MB598545 LH	MITSUBISHI	DELICA NEW L300 87-	CONTROL ARM	FRONT LOWER W/ BJ LH
UTC06-2413	MB598546 RH	MITSUBISHI	DELICA NEW L300 87-	CONTROL ARM	FRONT LOWER W/ BJ RH
UTC06-2414	MB598547 LH	MITSUBISHI	DELICA 4WD 87-	CONTROL ARM	FRONT LOWER W/ BJ LH
UTC06-2415	MB598548 RH	MITSUBISHI	DELICA 4WD 87-	CONTROL ARM	FRONT LOWER W/ BJ RH
UTC06-2416	MB698511 LH	MITSUBISHI	DELICA 4WD 87-	CONTROL ARM	FRONT LOWER W/O BJ LH
UTC06-2417	MB698512 RH	MITSUBISHI	DELICA 4WD 87-	CONTROL ARM	FRONT LOWER W/O BJ RH
UTC06-2422	MB831035 LH	MITSUBISHI	MONTERO 92-00	CONTROL ARM	FRONT UPPER W/ BJ LH
UTC06-2422	MB831035 LH	MITSUBISHI	PAJERO 97-	CONTROL ARM	FRONT UPPER W/ BJ LH
UTC06-2423	MB831036 RH	MITSUBISHI	MONTERO 92-00	CONTROL ARM	FRONT UPPER W/ BJ RH
UTC06-2423	MB831036 RH	MITSUBISHI	PAJERO 97-	CONTROL ARM	FRONT UPPER W/ BJ RH



UNITEDTEK CORPORATION

Email: utk@seed.net.tw

UT NO.	OEM NO.	MAKE	DESCRIPTION	PART	NOTE
UTC06-4593	MB860408	MITSUBISHI	DELICA L200 83~94	CONTROL ARM	FRONT UPPER W/ BJ RH
UTC06-2426	MB912505	MITSUBISHI	ECLIPSE 96~99	CONTROL ARM	FRONT UPPER W/ BJ LH
UTC06-2426	MB912505 LH MR162	MITSUBISHI	GALANT 94~99	CONTROL ARM	FRONT UPPER W/ BJ LH
UTC06-2427	MB912506	MITSUBISHI	ECLIPSE 96~99	CONTROL ARM	FRONT UPPER W/ BJ RH
UTC06-2427	MB912506 RH MR162	MITSUBISHI	GALANT 94~99	CONTROL ARM	FRONT UPPER W/ BJ RH
UTC06-2430	MB949001	MITSUBISHI	ECLIPSE 96~99	CONTROL ARM	REAR,LOWER ASSY LH
UTC06-2430	MB949001 LH	MITSUBISHI	GALANT 94~99	CONTROL ARM	REAR,LOWER ARM ASSY LH
UTC06-2431	MB949002	MITSUBISHI	ECLIPSE 96~99	CONTROL ARM	REAR,LOWER ASSY RH
UTC06-2431	MB949002 RH	MITSUBISHI	GALANT 94~99	CONTROL ARM	REAR,LOWER ARM ASSY RH
UTC06-2436	MN101261 LH	MITSUBISHI	GALANT 04-08	CONTROL ARM	FRONT LOWER W/ BJ LH
UTC06-2436	MN101261 LH	MITSUBISHI	GRUNDER 05-	CONTROL ARM	FRONT LOWER W/ BJ R/L
UTC06-2437	MN101262 RH	MITSUBISHI	GALANT 04-08	CONTROL ARM	FRONT LOWER W/ BJ RH
UTC06-2437	MN101262 RH	MITSUBISHI	GRUNDER 05-	CONTROL ARM	FRONT LOWER W/ BJ R/L
UTC06-2438	MN101741 LH	MITSUBISHI	OUTLANDER 01-06	CONTROL ARM	FRONT LOWER W/ BJ LH
UTC06-2439	MN101742 RH	MITSUBISHI	OUTLANDER 01-06	CONTROL ARM	FRONT LOWER W/ BJ RH
UTC06-4561	MN186655	MITSUBISHI	ECLIPSE 06-11	CONTROL ARM	LOW. LH
UTC06-4561	MN186655	MITSUBISHI	GALANT 04-11	CONTROL ARM	LOW. LH
UTC06-4562	MN186656	MITSUBISHI	ECLIPSE 06-11	CONTROL ARM	LOW, RH
UTC06-4562	MN186656	MITSUBISHI	GALANT 04-11	CONTROL ARM	LOW, RH
UTC10-4753	MR112709	MITSUBISHI	DELICA 02-14	BUSHING	R/L
UTC06-4750	MR162693	MITSUBISHI	DELICA 02-14	CONTROL ARM	LH
UTC06-2440	MR162693 LH	MITSUBISHI	SPACE GEAR 96	CONTROL ARM	FRONT LOWER W/ BJ LH 2WD
UTC06-4751	MR162694	MITSUBISHI	DELICA 02-14	CONTROL ARM	RH
UTC06-2441	MR162694 RH	MITSUBISHI	SPACE GEAR 96	CONTROL ARM	FRONT LOWER W/ BJ RH 2WD
UTC06-2442	MR210430 LH	MITSUBISHI	FREeca 96-	CONTROL ARM	FRONT LOWER W/ BJ LH
UTC06-2443	MR210431 RH	MITSUBISHI	FREeca 96-	CONTROL ARM	FRONT LOWER W/ BJ RH
UTC06-2444	MR210442 R/L	MITSUBISHI	FREeca 96-	CONTROL ARM	FRONT UPPER W/ BJ R/L
UTC06-3917	MR241341 MR43970	MITSUBISHI	MIRAGE 97-02	CONTROL ARM	LOW, LH
UTC06-3918	MR241342 MR43970	MITSUBISHI	MIRAGE 97-02	CONTROL ARM	LOW, RH
UTC06-2447	MR267593 LH	MITSUBISHI	DELICA 97-	CONTROL ARM	FRONT,LOWER W/O BJ LH
UTC06-2448	MR267594 RH	MITSUBISHI	DELICA 97-	CONTROL ARM	FRONT,LOWER W/O BJ RH
UTC06-3765	MR296287	MITSUBISHI	ECLIPSE 95-99	CONTROL ARM	LOW, LH
UTC06-3764	MR296288	MITSUBISHI	ECLIPSE 95-99	CONTROL ARM	LOW, RH
UTC06-3729	MR296289	MITSUBISHI	GALANT 94-98	CONTROL ARM	LOW, LH
UTC06-3728	MR296290	MITSUBISHI	GALANT 94-98	CONTROL ARM	LOW, RH
UTC06-1326	MR296295	MITSUBISHI	ECLIPSE 95-99	CONTROL ARM	LOW
UTC06-1326	MR296295	MITSUBISHI	GALANT 94-98	CONTROL ARM	FRONT LOWER
UTC06-1325	MR296296	MITSUBISHI	ECLIPSE 95-99	CONTROL ARM	LOW
UTC06-1325	MR296296	MITSUBISHI	GALANT 94-98	CONTROL ARM	FRONT LOWER
UTC06-2449	MR297537	MITSUBISHI	ECLIPSE 96~99	CONTROL ARM	REAR,UPPER 2.0/2.5 LH
UTC06-2449	MR297537 LH	MITSUBISHI	GALANT 94~99	CONTROL ARM	REAR,UPPER ARM 2.0/2.5 LH
UTC06-2450	MR297538	MITSUBISHI	ECLIPSE 96~99	CONTROL ARM	REAR,UPPER 2.0/2.4 RH
UTC06-2450	MR297538 RH	MITSUBISHI	GALANT 94~99	CONTROL ARM	REAR,UPPER ARM 2.0/2.4 RH
UTC06-2452	MR369791 LH	MITSUBISHI	GALANT 99-01	CONTROL ARM	FRONT LOWER W/ BJ LH
UTC06-2453	MR369792 RH	MITSUBISHI	GALANT 99-01	CONTROL ARM	FRONT LOWER W/ BJ RH
UTC06-2454	MR376005 LH	MITSUBISHI	SPACE GEAR 96	CONTROL ARM	FRONT LOWER W/ BJ LH 2WD



UNITEDTEK CORPORATION

Email: utk@seed.net.tw

<u>UT NO.</u>	<u>OEM NO.</u>	<u>MAKE</u>	<u>DESCRIPTION</u>	<u>PART</u>	<u>NOTE</u>
UTC06-2455	MR376006 RH	MITSUBISHI	SPACE GEAR 96	CONTROL ARM	FRONT UPPER W/ BJ RH 2WD
UTC06-2456	MR403419 LH	MITSUBISHI	LANCER 02-06	CONTROL ARM	FRONT LOWER W/ BJ LH
UTC06-2457	MR403420 RH	MITSUBISHI	LANCER 02-06	CONTROL ARM	FRONT LOWER W/ BJ RH
UTC06-4565	MR455737	MITSUBISHI	GALANT 99-03	CONTROL ARM	LOW, LH
UTC06-2458	MR455737 LH	MITSUBISHI	GALANT 99-03	CONTROL ARM	FRONT LOWER W/ BJ LH
UTC06-4566	MR455738	MITSUBISHI	GALANT 99-03	CONTROL ARM	LOW, RH
UTC06-2459	MR455738 RH	MITSUBISHI	GALANT 99-03	CONTROL ARM	FRONT LOWER W/ BJ RH
UTC06-2460	MR491911 R/L	MITSUBISHI	LANCER 02-06	CONTROL ARM	REAR,UPPER R/L
UTC06-2461	MR491962 R/L	MITSUBISHI	LANCER 02-06	CONTROL ARM	REAR LOWER ASSY R/L
UTC06-4567	MR496795	MITSUBISHI	MONTERO 01-06	CONTROL ARM	LOW, LH
UTC06-4568	MR496796	MITSUBISHI	MONTERO 01-06	CONTROL ARM	LOW, RH
UTC06-2462	MR554375 LH	MITSUBISHI	GALANT 01-03	CONTROL ARM	FRONT LOWER W/ BJ LH
UTC06-2463	MR554376 RH	MITSUBISHI	GALANT 01-03	CONTROL ARM	FRONT LOWER W/ BJ RH
UTC06-2464	MR589033 LH	MITSUBISHI	SAVRIN 02-	CONTROL ARM	FRONT LOWER W/ BJ LH
UTC06-2465	MR589034 RH	MITSUBISHI	SAVRIN 02-	CONTROL ARM	FRONT LOWER W/ BJ RH
UTC06-4569	MR589421	MITSUBISHI	ENDEAVOR 04-11	CONTROL ARM	LOW. LH
UTC06-4570	MR589422	MITSUBISHI	ENDEAVOR 04-11	CONTROL ARM	LOW, RH
UTC06-2084	54500-0B000	NISSAN	QUEST 93~98	CONTROL ARM	FRONT LOWER W/O BJ RH
UTC06-2085	54500-0M010	NISSAN	SENTRA(B14)95-	CONTROL ARM	FRONT LOWER W/ BJ RH
UTC06-2086	54500-0W000	NISSAN	PATHFINDER 97-03	CONTROL ARM	FRONT LOWER W/O BJ RH
UTC06-2088	54500-1AA1A RH	NISSAN	MURANO 09-	CONTROL ARM	FRONT LOWER W/ BJ RH
UTC06-4288	54500-1AT0B	NISSAN	MURANO 09-11	CONTROL ARM	LOW, RH
UTC06-4290	54500-1JY0A	NISSAN	CUBE 09-11	CONTROL ARM	LOW, RH
UTC06-2095	54500-2B010	NISSAN	ALTIMA(U13)93~97	CONTROL ARM	FRONT LOWER W/ BJ RH
UTC06-2097	54500-2F500 RH	NISSAN	PRIMERA 97-	CONTROL ARM	FRONT LOWER W/ BJ RH
UTC06-2099	54500-2Y411 RH	NISSAN	MAXIMA 00-03	CONTROL ARM	FRONT LOWER W/ BJ RH
UTC06-3904	54500-2Y412	NISSAN	MAXIMA 00-03	CONTROL ARM	LOW, RH
UTC06-2102	54500-41U01	NISSAN	CEFIRO 95-99(A32)	CONTROL ARM	FRONT LOWER W/BJ RH
UTC06-2102	54500-41U01 RH	NISSAN	MAXIMA 95-99	CONTROL ARM	FRONT LOWER W/BJ RH
UTC06-3902	54500-41U02	NISSAN	MAXIMA 95-99	CONTROL ARM	LOW, RH
UTC06-2103	54500-44B00 RH	NISSAN	MARCH(K11)92-	CONTROL ARM	FRONT LOWER W/ BJ RH
UTC06-2104	54500-4B000	NISSAN	SUNNY 95-01	CONTROL ARM	FRONT LOWER W/ BJ RH
UTC06-2105	54500-4M410	NISSAN	SENTRA(B15)01-06	CONTROL ARM	FRONT LOWER W/ BJ RH
UTC06-2105	54500-4M410	NISSAN	SUNNY(N16) 02-	CONTROL ARM	FRONT LOWER W/ BJ RH
UTC06-2105	54500-4M410 RH	NISSAN	ALMERA 02-	CONTROL ARM	FRONT LOWER W/ BJ RH
UTC06-2106	54500-4N000	NISSAN	SERENA 01-(C24)	CONTROL ARM	FRONT, LOWER ARM W/ BJ RH
UTC06-2107	54500-50A00	NISSAN	SENTRA(B12)86~90	CONTROL ARM	FRONT LOWER W/ BJ RH
UTC06-2108	54500-50J25	NISSAN	PRIMERA(P10)91~96	CONTROL ARM	FRONT LOWER W/ BJ RH
UTC06-2109	54500-52Y10 RH	NISSAN	SENTRA(B13)91~95	CONTROL ARM	FRONT LOWER W/ BJ RH
UTC06-2110	54500-52Y70	NISSAN	SUNNY(N14)	CONTROL ARM	FRONT LOWER W/ BJ RH
UTC06-2111	54500-7B000 RH	NISSAN	QUEST 99-04	CONTROL ARM	FRONT LOWER W/O BJ RH
UTC06-2112	54500-7S000 RH	NISSAN	ARMADA 04-	CONTROL ARM	FRONT LOWER W/ BJ RH
UTC06-2112	54500-7S000 RH	NISSAN	TITAN 04-	CONTROL ARM	FRONT LOWER W/ BJ RH
UTC06-2113	54500-7Y000	NISSAN	ALTIMA 02-06	CONTROL ARM	FRONT LOWER W/ BJ RH
UTC06-2113	54500-7Y000	NISSAN	MAXIMA 04-08	CONTROL ARM	FRONT LOWER W/ BJ RH
UTC06-3551	54500-7Y00A	NISSAN	MAXIMA 04-08	CONTROL ARM	LOW, RH
UTC06-2114	54500-85E01 RH	NISSAN	MAXIMA 89~94	CONTROL ARM	FRONT LOWER W/ BJ RH
UTC06-2115	54500-8H310	NISSAN	X-TRAIL(T30)02-	CONTROL ARM	FRONT LOWER W/ BJ RH
UTC06-3551	54500-8J000	NISSAN	ALTIMA 02-06	CONTROL ARM	LOW, RH
UTC06-4308	54500-9B001	NISSAN	ALTIMA 93-97	CONTROL ARM	LOW, RH
UTC06-2116	54500-9E000	NISSAN	ALTIMA 98-01	CONTROL ARM	FRONT LOWER W/ BJ RH
UTC06-4309	54500-9E000	NISSAN	ALTIMA 98-01	CONTROL ARM	LOW, RH



UNITEDTEK CORPORATION

Email: utk@seed.net.tw

<u>UT NO.</u>	<u>OEM NO.</u>	<u>MAKE</u>	<u>DESCRIPTION</u>	<u>PART</u>	<u>NOTE</u>
UTC06-4310	54500-9N00A	NISSAN	MAXIMA 09-12	CONTROL ARM	LOW, RH
UTC06-2117	54500-9N00A RH	NISSAN	MAXIMA 09-	CONTROL ARM	FRONT LOWER W/ BJ RH
UTC06-2118	54500-9W200 RH	NISSAN	TEANA(JA)03-	CONTROL ARM	FRONT LOWER W/ BJ RH
UTC06-2120	54500-AV606 RH	NISSAN	PRIMERA P12 02-	CONTROL ARM	FRONT LOWER W/ BJ RH
UTC06-2487	54500-CK000 RH	NISSAN	QUEST 05-	CONTROL ARM	FRONT LOWER W/ BJ
UTC06-2122	54500-EA000	NISSAN	PATHFINDER 04-	CONTROL ARM	FRONT LOWER W/ BJ RH
UTC06-2122	54500-EA000	NISSAN	X-TERRA 05	CONTROL ARM	FRONT LOWER W/ BJ RH
UTC06-2122	54500-EA000 RH	NISSAN	FRONTIER 05-	CONTROL ARM	FRONT LOWER W/ BJ RH
UTC06-4312	54500-EL00A	NISSAN	VERSA 07-11	CONTROL ARM	LOW, RH
UTC06-2491	54500-ET000	NISSAN	SENTRA 07-	CONTROL ARM	FRONT LOWER W/ BJ RH
UTC06-2491	54500-ET000	NISSAN	SUNNY ALMERA B16 07-	CONTROL ARM	FRONT LOWER W/ BJ RH
UTC06-2124	54500-EW000 RH	NISSAN	TIIDA 07-	CONTROL ARM	FRONT LOWER W/ BJ RH
UTC06-2124	54500-EW000 RH	NISSAN	VERSA 07-	CONTROL ARM	FRONT LOWER W/ BJ RH
UTC06-2126	54500-JA00B	NISSAN	ALTIMA 08-	CONTROL ARM	FRONT LOWER W/ BJ RH
UTC06-4313	54500-JB00B	NISSAN	ALTIMA 07-11	CONTROL ARM	LOW, RH
UTC06-2127	54500-JD000	NISSAN	ROGUE 08-	CONTROL ARM	FRONT LOWER W/ BJ RH
UTC06-4314	54500-JG00A	NISSAN	ROGUE 08-11	CONTROL ARM	LOW, RH
UTC06-2131	54500-JN01A RH	NISSAN	TEANA 08-	CONTROL ARM	FRONT LOWER W/ BJ RH
UTC06-2132	54501-0B000	NISSAN	QUEST 93~98	CONTROL ARM	FRONT LOWER W/O BJ LH
UTC06-2133	54501-0M010	NISSAN	SENTRA(B14)95-	CONTROL ARM	FRONT LOWER W/ BJ LH
UTC06-2134	54501-0W000	NISSAN	PATHFINDER 97-03	CONTROL ARM	FRONT LOWER W/O BJ LH
UTC06-2136	54501-1AA1A LH	NISSAN	MURANO 09-	CONTROL ARM	FRONT LOWER W/ BJ LH
UTC06-4316	54501-1AT0B	NISSAN	MURANO 09-11	CONTROL ARM	LOW, LH
UTC06-4318	54501-1JY0A	NISSAN	CUBE 09-11	CONTROL ARM	LOW, LH
UTC06-4319	54501-1KA0B	NISSAN	JUKE 11-	CONTROL ARM	LOW, LH
UTC06-2141	54501-2B010	NISSAN	ALTIMA(U13)93~97	CONTROL ARM	FRONT LOWER W/ BJ LH
UTC06-2143	54501-2F500 LH	NISSAN	PRIMERA 97-	CONTROL ARM	FRONT LOWER W/ BJ LH
UTC06-2145	54501-2Y411 LH	NISSAN	MAXIMA 00-03	CONTROL ARM	FRONT LOWER W/ BJ LH
UTC06-3905	54501-2Y412	NISSAN	MAXIMA 00-03	CONTROL ARM	LOW, LH
UTC06-2148	54501-41U01	NISSAN	CEFIRO 95-99(A32)	CONTROL ARM	FRONT LOWER W/BJ LH
UTC06-2148	54501-41U01 LH	NISSAN	MAXIMA 95-99	CONTROL ARM	FRONT LOWER W/BJ LH
UTC06-3903	54501-41U02	NISSAN	MAXIMA 95-99	CONTROL ARM	LOW, LH
UTC06-2149	54501-44B00 LH	NISSAN	MARCH(K11)92-	CONTROL ARM	FRONT LOWER W/ BJ LH
UTC06-2150	54501-4B000	NISSAN	SUNNY 95-01	CONTROL ARM	FRONT LOWER W/ BJ LH
UTC06-2151	54501-4M410	NISSAN	SENTRA(B15)01-06	CONTROL ARM	FRONT LOWER W/ BJ LH
UTC06-2151	54501-4M410	NISSAN	SUNNY(N16) 02-	CONTROL ARM	FRONT LOWER W/ BJ LH
UTC06-2151	54501-4M410 LH	NISSAN	ALMERA 02-	CONTROL ARM	FRONT LOWER W/ BJ LH
UTC06-2152	54501-4N000	NISSAN	SERENA 01-(C24)	CONTROL ARM	FRONT, LOWER ARM W/ BJ LH
UTC06-2153	54501-50A00 LH	NISSAN	SENTRA(B12)86~90	CONTROL ARM	FRONT LOWER W/ BJ LH
UTC06-2154	54501-50J25	NISSAN	PRIMERA(P10)91~96	CONTROL ARM	FRONT LOWER W/ BJ LH
UTC06-2155	54501-52Y10 LH	NISSAN	SENTRA(B13)91~95	CONTROL ARM	FRONT LOWER W/ BJ LH
UTC06-2156	54501-52Y70	NISSAN	SUNNY(N14)	CONTROL ARM	FRONT LOWER W/ BJ LH
UTC06-2157	54501-7B000 LH	NISSAN	QUEST 99-04	CONTROL ARM	FRONT LOWER W/O BJ LH
UTC06-2158	54501-7S000 LH	NISSAN	ARMADA 04-	CONTROL ARM	FRONT LOWER W/ BJ LH
UTC06-2158	54501-7S000 LH	NISSAN	TITAN 04-	CONTROL ARM	FRONT LOWER W/ BJ LH
UTC06-2159	54501-7Y000	NISSAN	ALTIMA 02-06	CONTROL ARM	FRONT LOWER W/ BJ LH
UTC06-2159	54501-7Y000	NISSAN	MAXIMA 04-08	CONTROL ARM	FRONT LOWER W/ BJ LH
UTC06-3552	54501-7Y00A	NISSAN	MAXIMA 04-08	CONTROL ARM	LOW, LH
UTC06-2160	54501-85E01 LH	NISSAN	MAXIMA 89~94	CONTROL ARM	FRONT LOWER W/ BJ LH
UTC06-2161	54501-8H310	NISSAN	X-TRAIL(T30)02-	CONTROL ARM	FRONT LOWER W/ BJ LH
UTC06-3552	54501-8J000	NISSAN	ALTIMA 02-06	CONTROL ARM	LOW, LH
UTC06-4337	54501-9B001	NISSAN	ALTIMA 93-97	CONTROL ARM	LOW, LH
UTC06-2162	54501-9E000	NISSAN	ALTIMA 98-01	CONTROL ARM	FRONT LOWER W/ BJ LH



UNITEDTEK CORPORATION

Email: utk@seed.net.tw

<u>UT NO.</u>	<u>OEM NO.</u>	<u>MAKE</u>	<u>DESCRIPTION</u>	<u>PART</u>	<u>NOTE</u>
UTC06-4338	54501-9E000	NISSAN	ALTIMA 98-01	CONTROL ARM	LOW, LH
UTC06-4339	54501-9N00A	NISSAN	MAXIMA 09-12	CONTROL ARM	LOW, LH
UTC06-2163	54501-9N00A LH	NISSAN	MAXIMA 09-	CONTROL ARM	FRONT LOWER W/ BJ LH
UTC06-2164	54501-9W200 LH	NISSAN	TEANA(JA)03-	CONTROL ARM	FRONT LOWER W/ BJ LH
UTC06-2166	54501-AV606 LH	NISSAN	PRIMERA P12 02-	CONTROL ARM	FRONT LOWER W/ BJ LH
UTC06-4340	54501-CC40E	NISSAN	MURANO 03-07	CONTROL ARM	LOW, LH
UTC06-2488	54501-CK000 LH	NISSAN	QUEST 05-	CONTROL ARM	FRONT LOWER W/ BJ
UTC06-2168	54501-EA000	NISSAN	PATHFINDER 04-	CONTROL ARM	FRONT LOWER W/ BJ LH
UTC06-2168	54501-EA000	NISSAN	X-TERRA 05	CONTROL ARM	FRONT LOWER W/ BJ LH
UTC06-2168	54501-EA000 LH	NISSAN	FRONTIER 05-	CONTROL ARM	FRONT LOWER W/ BJ LH
UTC06-4342	54501-EL00A	NISSAN	VERSA 07-11	CONTROL ARM	LOW, LH
UTC06-2492	54501-ET000	NISSAN	SENTRA 07-	CONTROL ARM	FRONT LOWER W/ BJ LH
UTC06-2492	54501-ET000	NISSAN	SUNNY ALMERA B16 07-	CONTROL ARM	FRONT LOWER W/ BJ LH
UTC06-2170	54501-EW000 LH	NISSAN	TIIDA 07-	CONTROL ARM	FRONT LOWER W/ BJ LH
UTC06-2170	54501-EW000 LH	NISSAN	VERSA 07-	CONTROL ARM	FRONT LOWER W/ BJ LH
UTC06-2172	54501-JA00B	NISSAN	ALTIMA 08-	CONTROL ARM	FRONT LOWER W/ BJ LH
UTC06-4343	54501-JB00B	NISSAN	ALTIMA 07-11	CONTROL ARM	LOW, LH
UTC06-2173	54501-JD000	NISSAN	ROGUE 08-	CONTROL ARM	FRONT LOWER W/ BJ LH
UTC06-4344	54501-JG00A	NISSAN	ROGUE 08-11	CONTROL ARM	LOW, LH
UTC06-2177	54501-JN01A LH	NISSAN	TEANA 08-	CONTROL ARM	FRONT LOWER W/ BJ LH
UTC06-2181	54524-2F010 RH	NISSAN	PRIMERA 97-	CONTROL ARM	FRONT UPPER W/ BUSHING RH
UTC06-2183	54524-2J001	NISSAN	PRIMERA(P10)91~96	CONTROL ARM	FRONT UPPER ARM RH
UTC06-2184	54524-2S486 RH	NISSAN	D22 PICKUP 02-	CONTROL ARM	FRONT UPPER W/ BJ
UTC06-2185	54524-7S000 RH	NISSAN	ARMADA 04-	CONTROL ARM	FRONT UPPER W/ BJ RH
UTC06-2185	54524-7S000 RH	NISSAN	TITAN 04-	CONTROL ARM	FRONT UPPER W/ BJ RH
UTC06-2187	54524-AV601 RH	NISSAN	PRIMERA P12 02-	CONTROL ARM	FRONT UPPER W/ BJ RH
UTC06-2188	54524-EA000	NISSAN	PATHFINDER 04-	CONTROL ARM	FRONT UPPER W/ BJ RH
UTC06-2188	54524-EA000	NISSAN	X-TERRA 05	CONTROL ARM	FRONT UPPER W/ BJ RH
UTC06-2188	54524-EA000 RH	NISSAN	FRONTIER 05-	CONTROL ARM	FRONT UPPER W/ BJ RH
UTC06-2192	54525-2F010 LH	NISSAN	PRIMERA 97-	CONTROL ARM	FRONT UPPER W/ BUSHING LH
UTC06-2193	54525-2J001	NISSAN	PRIMERA(P10)91~96	CONTROL ARM	FRONT UPPER ARM LH
UTC06-2194	54525-2S486 LH	NISSAN	D22 PICKUP 02-	CONTROL ARM	FRONT UPPER W/ BJ
UTC06-2195	54525-7S000 LH	NISSAN	ARMADA 04-	CONTROL ARM	FRONT UPPER W/ BJ LH
UTC06-2195	54525-7S000 LH	NISSAN	TITAN 04-	CONTROL ARM	FRONT UPPER W/ BJ LH
UTC06-2197	54525-AV601 LH	NISSAN	PRIMERA P12 02-	CONTROL ARM	FRONT UPPER W/ BJ LH
UTC06-2198	54525-EA000	NISSAN	PATHFINDER 04-	CONTROL ARM	FRONT UPPER W/ BJ LH
UTC06-2198	54525-EA000	NISSAN	X-TERRA 05	CONTROL ARM	FRONT UPPER W/ BJ LH
UTC06-2198	54525-EA000 LH	NISSAN	FRONTIER 05-	CONTROL ARM	FRONT UPPER W/ BJ LH
UTC06-2202	54570-01E01	NISSAN	BLUEBIRD 83~91	CONTROL ARM	FRONT LOWER W/O BJ RH
UTC06-2203	54571-01E01	NISSAN	BLUEBIRD 83~91	CONTROL ARM	FRONT LOWER W/O BJ LH
UTC06-2204	55501-1AA0A RH	NISSAN	MURANO 09-	CONTROL ARM	REAR UPPER W/ BJ RH
UTC06-2207	55501-9N00A RH	NISSAN	MAXIMA 09-	CONTROL ARM	FRONT UPPER W/ BJ RH
UTC06-2489	55501-CK000 RH	NISSAN	QUEST 05-	CONTROL ARM	FRONT UPPER W/ BJ
UTC06-2211	55501-JA00A	NISSAN	ALTIMA 08-	CONTROL ARM	FRONT UPPER W/ BJ RH
UTC06-2214	55501-ZD90A	NISSAN	ALTIMA 02-06	CONTROL ARM	REAR UPPER W/BJ RH
UTC06-2214	55501-ZD90A	NISSAN	MAXIMA 04-08	CONTROL ARM	REAR UPPER W/BJ RH
UTC06-2215	55502-1AA0A LH	NISSAN	MURANO 09-	CONTROL ARM	REAR UPPER W/ BJ LH
UTC06-2218	55502-9N00A LH	NISSAN	MAXIMA 09-	CONTROL ARM	FRONT UPPER W/ BJ LH
UTC06-2490	55502-CK000 LH	NISSAN	QUEST 05-	CONTROL ARM	FRONT UPPER W/ BJ
UTC06-2222	55502-JA00A	NISSAN	ALTIMA 08-	CONTROL ARM	FRONT UPPER W/ BJ LH
UTC06-2225	55502-ZD90A	NISSAN	ALTIMA 02-06	CONTROL ARM	REAR UPPER W/BJ LH
UTC06-2225	55502-ZD90A	NISSAN	MAXIMA 04-08	CONTROL ARM	REAR UPPER W/BJ LH



UNITEDTEK CORPORATION

Email: utk@seed.net.tw

<u>UT NO.</u>	<u>OEM NO.</u>	<u>MAKE</u>	<u>DESCRIPTION</u>	<u>PART</u>	<u>NOTE</u>
54500-CC40B RH	KTC06-2483	NISSAN	MURANO 03-07	CONTROL ARM	FRONT LOWER W/ BJ
54501-CC40B LH	KTC06-2484	NISSAN	MURANO 03-07	CONTROL ARM	FRONT LOWER W/ BJ
55501-CA00A RH	KTC06-2485	NISSAN	MURANO 03-07	CONTROL ARM	FRONT UPPER W/ BJ
55502-CA00A LH	KTC06-2486	NISSAN	MURANO 03-07	CONTROL ARM	FRONT UPPER W/ BJ
UTC06-4145	48068-12300	SCION	TC 11-	CONTROL ARM W/O BJ	LOW, RH
UTC06-4145	48068-12300	SCION	XB 08-12	CONTROL ARM W/O BJ	LOW, RH
UTC06-4147	48068-19176	SCION	XB 04-06	CONTROL ARM 2004	LOW, RH
UTC06-3932	48068-21020	SCION	TC 05-10	CONTROL ARM W/O BJ	LOW, RH
UTC06-3557	48068-59065	SCION	XB 04-06	CONTROL ARM 05-06	LOW, RH
UTC06-4155	48068-59145	SCION	XD 08-11	CONTROL ARM	LOW, RH
UTC06-4168	48069-12300	SCION	TC 11-	CONTROL ARM W/O BJ	LOW, LH
UTC06-4168	48069-12300	SCION	XB 08-12	CONTROL ARM W/O BJ	LOW, LH
UTC06-4170	48069-19156	SCION	XB 04-06	CONTROL ARM 2004	LOW, LH
UTC06-3933	48069-21020	SCION	TC 05-10	CONTROL ARM W/O BJ	LOW, LH
UTC06-3558	48069-59065	SCION	XB 04-06	CONTROL ARM 05-06	LOW, LH
UTC06-1695	45200-50E00 R/L	SUZUKI	ALTO 84-88	CONTROL ARM	FRONT LOWER W/ BJ R/L
UTC06-1696	45200-60830	SUZUKI	ESCUDE 98-	CONTROL ARM	FRONT LOWER W/O BJ RH
UTC06-1696	45200-60830	SUZUKI	SIDEKICK 89-98	CONTROL ARM	FRONT LOWER W/O BJ RH
UTC06-1697	45200-60840	SUZUKI	ESCUDE 98-	CONTROL ARM	FRONT LOWER W/O BJ LH
UTC06-1697	45200-60840	SUZUKI	SIDEKICK 89-98	CONTROL ARM	FRONT LOWER W/O BJ LH
UTC06-1698	45200-61J00	SUZUKI	CARRY 08-	CONTROL ARM	FRONT LOWER W/ BJ RH
UTC06-1699	45200-75F10	SUZUKI	WAGON R 00-	CONTROL ARM	FRONT LOWER W/ BJ R/L
UTC06-1700	45200-76G00	SUZUKI	SOLIO 02-	CONTROL ARM	FRONT LOWER W/ BJ R/L
UTC06-1701	45200-81A10	SUZUKI	JIMNY 00-	CONTROL ARM	R/L
UTC06-1702	45200-82000	SUZUKI	SWIFT 85-	CONTROL ARM	FRONT LOWER W/ BJ R/L
UTC06-1704	45201-54G01	SUZUKI	AERIO 02-03	CONTROL ARM	FRONT LOWER W/ BJ RH
UTC06-1705	45201-59J00	SUZUKI	AERIO 04-06	CONTROL ARM	FRONT LOWER W/ BJ RH
UTC06-1706	45201-60B01	SUZUKI	SWIFT 89~94	CONTROL ARM	FRONT LOWER W/ BJ RH
UTC06-1707	45201-61J00	SUZUKI	CARRY 08-	CONTROL ARM	FRONT LOWER W/ BJ LH
UTC06-1360	45201-63G01	SUZUKI	BALENO 95-	CONTROL ARM	LOW, RH
UTC06-1360	45201-63G01	SUZUKI	ESTEEM 95-02	CONTROL ARM	FRONT LOWER W/ BJ RH
UTC06-1360	45201-63G01	SUZUKI	SWIFT 95-	CONTROL ARM	LOW, RH
UTC06-1709	45201-63J00	SUZUKI	SWIFT 05-	CONTROL ARM	FRONT LOWER W/ BJ RH
UTC06-1710	45201-65D00	SUZUKI	GRAND VITARA 99-	CONTROL ARM	FRONT LOWER W/ BJ RH
UTC06-4111	45201-75L01	SUZUKI	KIZASHI 10-	CONTROL ARM	LOW, RH
UTC06-1712	45201-77A10	SUZUKI	CARRY	CONTROL ARM	FRONT LOWER W/ BJ RH
UTC06-1713	45201-77A10	SUZUKI	EVERY	CONTROL ARM	FRONT LOWER W/ BJ RH
UTC06-1715	45201-77E01	SUZUKI	VITARA 96-	CONTROL ARM	FRONT LOWER W/ BJ RH
UTC06-1715	45201-77E01	SUZUKI	SIDEKICK SPORT 89-98	CONTROL ARM	FRONT LOWER W/ BJ RH
UTC06-4112	45201-78K00	SUZUKI	GRAND VITARA 06-11	CONTROL ARM	LOW, RH
UTC06-1716	45201-79J00	SUZUKI	SX4 06~	CONTROL ARM	FRONT LOWER W/ BJ RH
UTC06-4113	45201-86Z00	SUZUKI	FORENZA 04-08	CONTROL ARM	LOW, RH
UTC06-4113	45201-86Z00	SUZUKI	VERONA 04-06	CONTROL ARM	LOW, RH
UTC06-1719	45202-54G01	SUZUKI	AERIO 02-03	CONTROL ARM	FRONT LOWER W/ BJ LH
UTC06-1719	45202-54G01	SUZUKI	AERIO 02-03	CONTROL ARM	LOW, LH
UTC06-1720	45202-59J00	SUZUKI	AERIO 04-06	CONTROL ARM	FRONT LOWER W/ BJ LH
UTC06-1721	45202-60B01	SUZUKI	SWIFT 89~94	CONTROL ARM	FRONT LOWER W/ BJ LH
UTC06-1361	45202-63G01	SUZUKI	BALENO 95-	CONTROL ARM	LOW, LH
UTC06-1361	45202-63G01	SUZUKI	ESTEEM 95-02	CONTROL ARM	FRONT LOWER W/ BJ LH
UTC06-1361	45202-63G01	SUZUKI	SWIFT 95-	CONTROL ARM	LOW, LH



UNITEDTEK CORPORATION

Email: utk@seed.net.tw

UT NO.	OEM NO.	MAKE	DESCRIPTION	PART	NOTE
UTC06-1723	45202-63J00	SUZUKI	SWIFT 05-	CONTROL ARM	FRONT LOWER W/ BJ LH
UTC06-1724	45202-65D00	SUZUKI	GRAND VITARA 99-	CONTROL ARM	FRONT LOWER W/ BJ LH
UTC06-4116	45202-75L00	SUZUKI	KIZASHI 10-	CONTROL ARM	LOW, LH
UTC06-1726	45202-77A10	SUZUKI	CARRY	CONTROL ARM	FRONT LOWER W/ BJ LH
UTC06-1727	45202-77A10	SUZUKI	EVERY	CONTROL ARM	FRONT LOWER W/ BJ LH
UTC06-1729	45202-77E01	SUZUKI	VITARA 96-	CONTROL ARM	FRONT LOWER W/ BJ LH
UTC06-1729	45202-77E01	SUZUKI	SIDEKICK SPORT 89-98	CONTROL ARM	FRONT LOWER W/ BJ LH
UTC06-4117	45202-78K00	SUZUKI	GRAND VITARA 06-11	CONTROL ARM	LOW, LH
UTC06-1730	45202-79J00	SUZUKI	SX4 06~	CONTROL ARM	FRONT LOWER W/ BJ LH
UTC06-4118	45202-86Z00	SUZUKI	FORENZA 04-08	CONTROL ARM	LOW, LH
UTC06-4118	45202-86Z00	SUZUKI	VERONA 04-06	CONTROL ARM	LOW, LH
UTC06-1731	46200-52E00	SUZUKI	WAGON R 00-	CONTROL ARM	REAR,TRAILING LINK R/L
UTC06-1732	46200-56B00	SUZUKI	ESCUDE 98-	CONTROL ARM	REAR UPPER W/BJ R/L
UTC06-1732	46200-56B00	SUZUKI	SIDEKICK 89-98	CONTROL ARM	REAR UPPER W/BJ R/L
UTC06-1733	46200-56B00	SUZUKI	VITARA 96-	CONTROL ARM	REAR,UPPER W/ BJ R/L
UTC06-1733	46200-56B00	SUZUKI	SIDEKICK SPORT 89-98	CONTROL ARM	REAR,UPPER W/ BJ R/L
UTC06-1734	46201-84G00	SUZUKI	SOLIO 02-	CONTROL ARM	REAR,TRAILING LINK RH
UTC06-1735	46202-84G00	SUZUKI	SOLIO 02-	CONTROL ARM	REAR,TRAILING LINK LH
UTC06-1738	46300-50G00	SUZUKI	SWIFT 95-00	CONTROL ARM	REAR,LATERAL LINK R/L
UTC06-1739	46300-60B10	SUZUKI	SWIFT 89~94	CONTROL ARM	REAR,LATERAL LINK R/L
UTC06-1740	46300-75F00	SUZUKI	SOLIO 02-	CONTROL ARM	REAR,LATERAL ROD R/L
UTC06-1741	46300-75F00	SUZUKI	WAGON R 00-	CONTROL ARM	REAR,LATERAL ROD R/L
UTC06-1742	46310-60A01	SUZUKI	ESCUDE 98-	CONTROL ARM	REAR,STRUT ROD RH
UTC06-1742	46310-60A01	SUZUKI	SIDEKICK 89-98	CONTROL ARM	REAR,STRUT ROD RH
UTC06-1743	46310-60A01	SUZUKI	VITARA 96-	CONTROL ARM	REAR,STRUT ROD RH
UTC06-1743	46310-60A01	SUZUKI	SIDEKICK SPORT 89-98	CONTROL ARM	REAR,STRUT ROD RH
UTC06-1744	46320-60A01	SUZUKI	ESCUDE 98-	CONTROL ARM	REAR,STRUT ROD LH
UTC06-1744	46320-60A01	SUZUKI	SIDEKICK 89-98	CONTROL ARM	REAR,STRUT ROD LH
UTC06-1745	46320-60A01	SUZUKI	VITARA 96-	CONTROL ARM	REAR,STRUT ROD LH
UTC06-1745	46320-60A01	SUZUKI	SIDEKICK SPORT 89-98	CONTROL ARM	REAR,STRUT ROD LH
UTC06-1764	48066-29075 RH	TOYOTA	HIACE 98-	CONTROL ARM	FRONT UPPE W/ BJ RH
UTC06-1765	48066-35060	TOYOTA	HILUX 83~88	CONTROL ARM	FRONT UPPER W/ BJ RH
UTC06-1766	48067-29075 LH	TOYOTA	HIACE 98-	CONTROL ARM	FRONT UPPE W/ BJ LH
UTC06-1767	48067-35060	TOYOTA	HILUX 83~88	CONTROL ARM	FRONT UPPER W/ BJ LH
UTC06-4136	48068-02021	TOYOTA	COROLLA 03-08	CONTROL ARM W/O BJ	LOW, RH
UTC06-4136	48068-02021	TOYOTA	MATRIX 03-08	CONTROL ARM W/O BJ	LOW, RH
UTC06-4137	48068-02190	TOYOTA	COROLLA 09-11	CONTROL ARM W/O BJ	LOW, RH
UTC06-4137	48068-02190	TOYOTA	MATRIX 09-11	CONTROL ARM W/O BJ	LOW, RH
UTC06-1768	48068-06040	TOYOTA	CAMRY 97-01	CONTROL ARM	FRONT LOWER W/O BJ RH
UTC06-1769	48068-06070 RH	TOYOTA	CAMRY 07-	CONTROL ARM	FRONT LOWER W/O BJ RH
UTC06-4138	48068-06100	TOYOTA	AVALON 05-11	CONTROL ARM W/O BJ	LOW, RH
UTC06-4138	48068-06100	TOYOTA	SOLARA 04-08	CONTROL ARM W/O BJ	LOW, RH
UTC06-4139	48068-06150	TOYOTA	CAMRY 07-11	CONTROL ARM W/O BJ	LOW, RH
UTC06-1771	48068-07030	TOYOTA	SOLARA 99-	CONTROL ARM	FRONT LOWER W/O BJ RH
UTC06-1771	48068-07030 RH	TOYOTA	AVALON 00~04	CONTROL ARM	FRONT LOWER W/O BJ RH
UTC06-1772	48068-08010	TOYOTA	SIENNA 98-03	CONTROL ARM	FRONT LOWER W/O BJ RH
UTC06-4140	48068-08011	TOYOTA	SIENNA 98-03	CONTROL ARM	LOW, W/O BJ RH
UTC06-1773	48068-08021	TOYOTA	SIENNA 04-06	CONTROL ARM	FRONT LOWER W/O BJ RH
UTC06-1774	48068-08021	TOYOTA	SIENNA 04-06	CONTROL ARM	FRONT LOWER W/ BJ RH
UTC06-4141	48068-08040	TOYOTA	SIENNA 11-	CONTROL ARM W/O BJ	LOW, RH
UTC06-1775	48068-09025	TOYOTA	ECHO 00-05	CONTROL ARM	FRONT LOWER W/ BJ RH
UTC06-1775	48068-09025 RH	TOYOTA	VIOS 02-	CONTROL ARM	FRONT LOWER W/ BJ RH
UTC06-4142	48068-0E010	TOYOTA	HIGHLANDER 01-07	CONTROL ARM W/O BJ	LOW, RH
UTC06-1776	48068-0M010 RH	TOYOTA	WISH 04-	CONTROL ARM	FRONT LOWER W/O BJ RH



UNITEDTEK CORPORATION

Email: utk@seed.net.tw

<u>UT NO.</u>	<u>OEM NO.</u>	<u>MAKE</u>	<u>DESCRIPTION</u>	<u>PART</u>	<u>NOTE</u>
UTC06-4143	48068-0R010	TOYOTA	RAV4 06-11	CONTROL ARM W/O BJ	LOW, RH
UTC06-4144	48068-0T011	TOYOTA	HIGHLANDER 10-11	CONTROL ARM	LOW, W/O BJ RH
UTC06-4144	48068-0T011	TOYOTA	VENZA 09-11	CONTROL ARM W/O BJ	LOW, RH
UTC06-1777	48068-12110	TOYOTA	COROLLA 87~91	CONTROL ARM	FRONT LOWER W/O BJ RH
UTC06-1778	48068-12140	TOYOTA	COROLLA 93~97	CONTROL ARM	FRONT LOWER W/O BJ RH
UTC06-3718	48068-12171	TOYOTA	COROLLA 98-02	CONTROL ARM W/O BJ	LOW, RH
UTC06-1779	48068-12180	TOYOTA	COROLLA 97-02	CONTROL ARM	FRONT LOWER W/O BJ RH
UTC06-1780	48068-12250	TOYOTA	COROLLA 01-07	CONTROL ARM	FRONT LOWER W/O BJ RH
UTC06-4146	48068-13010	TOYOTA	COROLLA 09-11	CONTROL ARM W/O BJ	LOW, RH
UTC06-1781	48068-16060	TOYOTA	PASEO 92~95	CONTROL ARM	FRONT LOWER W/O BJ RH
UTC06-1782	48068-16120	TOYOTA	TERCEL 91~97	CONTROL ARM	FRONT LOWER W/O BJ RH
UTC06-1783	48068-20200 RH	TOYOTA	CORONA 87~91	CONTROL ARM	FRONT LOWER W/O BJ RH
UTC06-1784	48068-20220 RH	TOYOTA	CORONA PREMIO 97-	CONTROL ARM	FRONT LOWER W/O BJ RH
UTC06-1785	48068-20260 RH	TOYOTA	CORONA 93~97	CONTROL ARM	FRONT LOWER W/O BJ RH
UTC06-4148	48068-20390	TOYOTA	COROLLA 03-08	CONTROL ARM W/O BJ	LOW, RH
UTC06-1786	48068-26071 RH	TOYOTA	HIACE 98-	CONTROL ARM	FRONT LOWER W/O BJ RH
UTC06-1787	48068-28020 RH	TOYOTA	KIJANG 86-	CONTROL ARM	FRONT LOWER W/O BJ RH
UTC06-1788	48068-28040 RH	TOYOTA	KIJANG 86-	CONTROL ARM	FRONT LOWER W/O BJ RH
UTC06-4149	48068-28120	TOYOTA	HIGHLANDER 01-07	CONTROL ARM W/O BJ	LOW, RH
UTC06-1789	48068-33010	TOYOTA	CAMRY 92~96	CONTROL ARM	FRONT LOWER W/O BJ RH
UTC06-1790	48068-33020	TOYOTA	AVALON 95~99	CONTROL ARM	FRONT LOWER W/O BJ RH
UTC06-3533	48068-33030	TOYOTA	AVALON 95-99	CONTROL ARM W/O BJ	LOW, RH
UTC06-1791	48068-42012	TOYOTA	RAV4 96-00	CONTROL ARM	FRONT LOWER W/O BJ RH
UTC06-3935	48068-42022	TOYOTA	RAV4 96-00	CONTROL ARM W/O BJ	LOW, RH
UTC06-1792	48068-42040	TOYOTA	RAV4 01-05	CONTROL ARM	FRONT LOWER W/O BJ RH
UTC06-1793	48068-46041 RH	TOYOTA	TERCEL 98-	CONTROL ARM	FRONT LOWER W/O BJ RH
UTC06-4150	48068-47040	TOYOTA	PRIUS 04-09	CONTROL ARM W/O BJ	LOW, RH
UTC06-4151	48068-47050	TOYOTA	PRIUS 10-	CONTROL ARM W/O BJ	LOW, RH
UTC06-4153	48068-48041	TOYOTA	HIGHLANDER 08-10	CONTROL ARM	LOW, W/O BJ RH
UTC06-4154	48068-59035	TOYOTA	ECHO 00-05	CONTROL ARM 00-03	
UTC06-1794	48068-59055	TOYOTA	ECHO 04-05	CONTROL ARM	FRONT LOWER W/ BJ RH
UTC06-1795	48068-59095 RH	TOYOTA	YARIS 06-09	CONTROL ARM	FRONT LOWER W/ BJ RH
UTC06-4155	48068-59145	TOYOTA	YARIS 07-11	CONTROL ARM	LOW, RH
UTC06-4156	48068-60010	TOYOTA	FJ CRUISER 07-11	CONTROL ARM 07-09	LOW, RH
UTC06-4157	48068-60030	TOYOTA	LAND CRUISER 08-11	CONTROL ARM	LOW, RH
UTC06-4158	48068-60040	TOYOTA	FJ CRUISER 07-11	CONTROL ARM 10-11	LOW, RH
UTC06-4159	48069-02021	TOYOTA	COROLLA 03-08	CONTROL ARM W/O BJ	LOW, LH
UTC06-4159	48069-02021	TOYOTA	MATRIX 03-08	CONTROL ARM W/O BJ	LOW, LH
UTC06-4160	48069-02190	TOYOTA	COROLLA 09-11	CONTROL ARM W/O BJ	LOW, LH
UTC06-4160	48069-02190	TOYOTA	MATRIX 09-11	CONTROL ARM W/O BJ	LOW, LH
UTC06-1799	48069-06040	TOYOTA	CAMRY 97-01	CONTROL ARM	FRONT LOWER W/O BJ LH
UTC06-1800	48069-06070 LH	TOYOTA	CAMRY 07-	CONTROL ARM	FRONT LOWER W/O BJ LH
UTC06-4161	48069-06100	TOYOTA	AVALON 05-11	CONTROL ARM W/O BJ	LOW, LH
UTC06-4161	48069-06100	TOYOTA	SOLARA 04-08	CONTROL ARM W/O BJ	LOW, LH
UTC06-4162	48069-06150	TOYOTA	CAMRY 07-11	CONTROL ARM W/O BJ	LOW, LH
UTC06-1802	48069-07030	TOYOTA	SOLARA 99-	CONTROL ARM	FRONT LOWER W/O BJ LH
UTC06-1802	48069-07030 LH	TOYOTA	AVALON 00~04	CONTROL ARM	FRONT LOWER W/O BJ LH
UTC06-1803	48069-08010	TOYOTA	SIENNA 98-03	CONTROL ARM	FRONT LOWER W/O BJ LH
UTC06-4163	48069-08011	TOYOTA	SIENNA 98-03	CONTROL ARM	LOW, W/O BJ LH
UTC06-1804	48069-08021	TOYOTA	SIENNA 04-06	CONTROL ARM	FRONT LOWER W/O BJ LH
UTC06-1805	48069-08021	TOYOTA	SIENNA 04-06	CONTROL ARM	FRONT LOWER W/ BJ LH
UTC06-4164	48069-08040	TOYOTA	SIENNA 11-	CONTROL ARM W/O BJ	LOW, LH
UTC06-1806	48069-09025	TOYOTA	ECHO 00-05	CONTROL ARM	FRONT LOWER W/ BJ LH
UTC06-1806	48069-09025 LH	TOYOTA	VIOS 02-	CONTROL ARM	FRONT LOWER W/ BJ LH



UNITEDTEK CORPORATION

Email: utk@seed.net.tw

<u>UT NO.</u>	<u>OEM NO.</u>	<u>MAKE</u>	<u>DESCRIPTION</u>	<u>PART</u>	<u>NOTE</u>
UTC06-4165	48069-0E010	TOYOTA	HIGHLANDER 01-07	CONTROL ARM W/O BJ	LOW, LH
UTC06-1807	48069-0M010 LH	TOYOTA	WISH 04-	CONTROL ARM	FRONT LOWER W/O BJ LH
UTC06-4166	48069-0R010	TOYOTA	RAV4 06-11	CONTROL ARM W/O BJ	LOW, LH
UTC06-4167	48069-0T011	TOYOTA	HIGHLANDER 10-11	CONTROL ARM	LOW, W/O BJ LH
UTC06-4167	48069-0T011	TOYOTA	VENZA 09-11	CONTROL ARM W/O BJ	LOW, LH
UTC06-1808	48069-12110	TOYOTA	COROLLA 87~91	CONTROL ARM	FRONT LOWER W/O BJ LH
UTC06-1809	48069-12140	TOYOTA	COROLLA 93~97	CONTROL ARM	FRONT LOWER W/O BJ LH
UTC06-3719	48069-12171	TOYOTA	COROLLA 98-02	CONTROL ARM W/O BJ	LOW, LH
UTC06-1810	48069-12180	TOYOTA	COROLLA 97-02	CONTROL ARM	FRONT LOWER W/O BJ LH
UTC06-1811	48069-12250	TOYOTA	COROLLA 01-07	CONTROL ARM	FRONT LOWER W/O BJ LH
UTC06-4169	48069-13010	TOYOTA	COROLLA 09-11	CONTROL ARM W/O BJ	LOW, LH
UTC06-1812	48069-16060	TOYOTA	PASEO 92~95	CONTROL ARM	FRONT LOWER W/O BJ LH
UTC06-1813	48069-16120	TOYOTA	TERCEL 91~97	CONTROL ARM	FRONT LOWER W/O BJ LH
UTC06-1814	48069-20200 LH	TOYOTA	CORONA 87~91	CONTROL ARM	FRONT LOWER W/O BJ LH
UTC06-1815	48069-20220 LH	TOYOTA	CORONA PREMIO 97-	CONTROL ARM	FRONT LOWER W/O BJ LH
UTC06-1816	48069-20260 LH	TOYOTA	CORONA 93~97	CONTROL ARM	FRONT LOWER W/O BJ LH
UTC06-4171	48069-20390	TOYOTA	COROLLA 03-08	CONTROL ARM W/O BJ	LOW, LH
UTC06-1817	48069-26071 LH	TOYOTA	HIACE 98-	CONTROL ARM	FRONT LOWER W/O BJ LH
UTC06-1818	48069-28020 LH	TOYOTA	KIJANG 86-	CONTROL ARM	FRONT LOWER W/O BJ LH
UTC06-1819	48069-28040 LH	TOYOTA	KIJANG 86-	CONTROL ARM	FRONT LOWER W/O BJ LH
UTC06-4172	48069-28120	TOYOTA	HIGHLANDER 01-07	CONTROL ARM W/O BJ	LOW, LH
UTC06-1820	48069-33020	TOYOTA	AVALON 95~99	CONTROL ARM	FRONT LOWER W/O BJ LH
UTC06-3534	48069-33030	TOYOTA	AVALON 95-99	CONTROL ARM W/O BJ	LOW, LH
UTC06-1821	48069-42012	TOYOTA	RAV4 96-00	CONTROL ARM	FRONT LOWER W/O BJ LH
UTC06-3934	48069-42022	TOYOTA	RAV4 96-00	CONTROL ARM W/O BJ	LOW, LH
UTC06-1822	48069-42040	TOYOTA	RAV4 01-05	CONTROL ARM	FRONT LOWER W/O BJ LH
UTC06-3928	48069-42041	TOYOTA	RAV4 04-05	CONTROL ARM W/O BJ	LOW, LH
UTC06-1823	48069-46041 LH	TOYOTA	TERCEL 98-	CONTROL ARM	FRONT LOWER W/O BJ LH
UTC06-4173	48069-47040	TOYOTA	PRIUS 04-09	CONTROL ARM W/O BJ	LOW, LH
UTC06-4174	48069-47050	TOYOTA	PRIUS 10-	CONTROL ARM W/O BJ	LOW, LH
UTC06-4176	48069-48041	TOYOTA	HIGHLANDER 08-10	CONTROL ARM	LOW, W/O BJ LH
UTC06-4177	48069-59035	TOYOTA	ECHO 00-05	CONTROL ARM 00-03	
UTC06-1824	48069-59055	TOYOTA	ECHO 04-05	CONTROL ARM	FRONT LOWER W/ BJ LH
UTC06-1825	48069-59095 LH	TOYOTA	YARIS 06-09	CONTROL ARM	FRONT LOWER W/ BJ LH
UTC06-4178	48069-59135	TOYOTA	YARIS 07-11	CONTROL ARM	LOW, LH
UTC06-4179	48069-60010	TOYOTA	FJ CRUISER 07-09	CONTROL ARM	LOW, LH
UTC06-4180	48069-60030	TOYOTA	LAND CRUISER 08-11	CONTROL ARM	LOW, LH
UTC06-4181	48069-60040	TOYOTA	FJ CRUISER 10-11	CONTROL ARM	LOW, LH
UTC06-1829	48610-28013 RH	TOYOTA	KIJANG 86-	CONTROL ARM	FRONT UPPER W/ BJ RH
UTC06-4193	48610-60030	TOYOTA	LAND CRUISER 08-11	CONTROL ARM	UP, RH
UTC06-4194	48610-60070	TOYOTA	FJ CRUISER 07-11	CONTROL ARM	UP, RH
UTC06-1831	48620-32040	TOYOTA	CAMRY 87~91	CONTROL ARM	FRONT LOWER W/ BJ RH
UTC06-1832	48630-28013 LH	TOYOTA	KIJANG 86-	CONTROL ARM	FRONT UPPER W/ BJ LH
UTC06-4196	48630-60030	TOYOTA	LAND CRUISER 08-11	CONTROL ARM	UP, LH
UTC06-4197	48630-60040	TOYOTA	FJ CRUISER 07-11	CONTROL ARM	UP, LH
UTC06-1834	48640-32040	TOYOTA	CAMRY 87~91	CONTROL ARM	FRONT LOWER W/ BJ LH
UTC06-1845	48710-33050	TOYOTA	SOLARA 99-	CONTROL ARM	REAR,FRONT LATERAL ROD R/L
UTC06-1845	48710-33050 R/L	TOYOTA	AVALON 00~04	CONTROL ARM	REAR,FRONT LATERAL ROD R/L
UTC06-1851	48720-42010	TOYOTA	RAV4 96-00	CONTROL ARM	REAR,LOWER ARM LINK RH
UTC06-1864	48730-42010	TOYOTA	RAV4 96-00	CONTROL ARM	REAR,LOWER ARM LINK LH
UTC06-1866	48730-AA020	TOYOTA	SOLARA 99-	CONTROL ARM	REAR,REAR LATERAL ROD LH
UTC06-1874	48740-AA020	TOYOTA	SOLARA 99-	CONTROL ARM	REAR,REAR LATERAL ROD LH



UNITEDTEK CORPORATION

Email: utk@seed.net.tw

<u>UT NO.</u>	<u>OEM NO.</u>	<u>MAKE</u>	<u>DESCRIPTION</u>	<u>PART</u>	<u>NOTE</u>
UTC06-1877	48770-42010	TOYOTA	RAV4 96-00	CONTROL ARM	REAR,UPPER ARM LINK RH
UTC06-1885	48780-33010	TOYOTA	SOLARA 99-	CONTROL ARM	REAR,STRUT ROD R/L
UTC06-1893	48790-42010	TOYOTA	RAV4 96-00	CONTROL ARM	REAR,UPPER ARM LINK LH
		TOYOTA	HILUX 88~94	CONTROL ARM	FRONT UPPER W/ BJ